


–weishaupt–

manual

Installation and operating instruction



| | | |
|----------|--|-----------|
| 1 | User instructions | 4 |
| 1.1 | Target group | 4 |
| 1.2 | Symbols | 4 |
| 1.3 | Guarantee and Liability | 5 |
| 2 | Safety | 6 |
| 2.1 | Designated application | 6 |
| 2.2 | When gas can be smelled | 6 |
| 2.3 | Safety measures | 6 |
| 2.3.1 | Personal protective equipment (PPE) | 6 |
| 2.3.2 | Normal operation | 6 |
| 2.3.3 | Electrical work | 7 |
| 2.3.4 | Gas supply | 7 |
| 2.4 | Alterations to the construction of the equipment | 7 |
| 2.5 | Noise emission | 7 |
| 2.6 | Disposal | 7 |
| 3 | Product description | 8 |
| 3.1 | Type key | 8 |
| 3.2 | Serial number | 8 |
| 3.3 | Function | 9 |
| 3.3.1 | Air supply | 9 |
| 3.3.2 | Gas supply | 10 |
| 3.3.3 | Electrical components | 11 |
| 3.3.4 | Program sequence | 12 |
| 3.4 | Technical data | 14 |
| 3.4.1 | Approval data | 14 |
| 3.4.2 | Electrical data | 14 |
| 3.4.3 | Ambient conditions | 14 |
| 3.4.4 | Fuels | 14 |
| 3.4.5 | Emissions | 15 |
| 3.4.6 | Rating | 16 |
| 3.4.7 | Dimensions | 17 |
| 3.4.8 | Weight | 18 |
| 4 | Installation | 19 |
| 4.1 | Installation conditions | 19 |
| 4.2 | Burner installation | 20 |
| 5 | Installation | 21 |
| 5.1 | Gas supply | 21 |
| 5.1.1 | Installing the gas valve train | 22 |
| 5.1.2 | Carry out soundness test of gas supply line and vent | 24 |
| 5.2 | Electrical connection | 25 |
| 6 | Operation | 26 |
| 6.1 | Operating panel | 26 |
| 6.2 | Display | 26 |
| 7 | Commissioning | 27 |
| 7.1 | Prerequisite | 27 |

| | | |
|-----------|--|-----------|
| 7.1.1 | Connect measuring devices | 28 |
| 7.1.2 | Check gas connection pressure | 29 |
| 7.1.3 | Check soundness of gas valve train | 30 |
| 7.1.4 | Purging the gas valve train | 31 |
| 7.1.5 | Preset pressure regulator | 32 |
| 7.1.6 | Set FRS pressure regulator (optional) | 35 |
| 7.1.7 | Setting values | 36 |
| 7.1.8 | Preset gas and air pressure switch | 39 |
| 7.2 | Adjusting the burner | 40 |
| 7.3 | Set pressure switches | 42 |
| 7.3.1 | Set gas pressure switch | 42 |
| 7.3.2 | Set air pressure switch | 43 |
| 7.4 | Concluding work | 44 |
| 7.5 | Check combustion | 45 |
| 7.6 | Calculate gas throughput | 46 |
| 8 | Shutdown | 47 |
| 9 | Servicing | 48 |
| 9.1 | Notes on servicing | 48 |
| 9.2 | Service plan | 50 |
| 9.3 | Removing and refitting mixing head | 51 |
| 9.4 | Set mixing head | 52 |
| 9.5 | Set ionisation and ignition electrodes | 53 |
| 9.6 | Service position | 53 |
| 9.7 | Removing and refitting fan wheel | 54 |
| 9.8 | Remove burner motor | 54 |
| 9.9 | Removing and refitting air regulator | 55 |
| 9.10 | Replacing coil on multifunction assembly | 56 |
| 9.11 | Replacing the fuse | 57 |
| 10 | Troubleshooting | 58 |
| 10.1 | Procedures for fault conditions | 58 |
| 10.1.1 | Illuminated push button off | 58 |
| 10.1.2 | Illuminated push button red | 59 |
| 10.1.3 | Illuminated push button flashes | 62 |
| 10.2 | Operating problems | 63 |
| 11 | Technical documentation | 64 |
| 11.1 | Wiring diagram | 64 |
| 11.2 | Conversion table unit of pressure | 66 |
| 11.3 | Appliance categories | 67 |
| 12 | Project planning | 71 |
| 12.1 | Continuous running fan or post-purge | 71 |
| 13 | Spares | 72 |
| 14 | Notes | 82 |
| 15 | Key word index | 85 |

1 User instructions

Translation of original
operating instructions

1 User instructions

This manual forms part of the equipment and must be kept on site.

Carefully read the manual prior to working on the unit.

1.1 Target group









The manual is intended for the operator and qualified personnel. It should be observed by all personnel working with the unit.

Work on the unit must only be carried out by personnel who have the relevant training and instruction.

Persons with limited physical, sensory or mental capabilities may only work on the unit if they are supervised or have been trained by an authorised person.

Children must not play with the unit.

1.2 Symbols

| | |
|---|---|
|  DANGER | Immediate danger with high risk. Non observance can lead to serious injury or death. |
|  WARNING | Danger with medium risk. Non observance can lead to environmental damage, serious injury or death. |
|  CAUTION | Danger with low risk. Non observance can cause damage to the equipment and injury to personnel. |
|  | Important information |
|  | Requires direct action |
|  | Result after an action |
|  | Itemisation |
|  | Range of values |

1.3 Guarantee and Liability

Guarantee and liability claims for personal and equipment damage are excluded, if they can be attributed to one or more of the following causes:

- non approved application,
- non-observance of the manual,
- operation with faulty safety equipment,
- continual operation despite a fault,
- improper installation, commissioning, operation and service,
- repairs, which have been carried out incorrectly,
- the use of non original Weishaupt parts,
- force majeure,
- unauthorised modifications made to the unit,
- the installation of additional components, which have not been tested with the unit,
- the installation of combustion chamber inserts, which impede full flame formation,
- unsuitable fuels,
- defects in the inlet lines.

2 Safety

2.1 Designated application

The burner is suitable for operation on heat exchangers to EN 303 and EN 676.

If the burner is not used on combustion chambers to EN 303 and EN 676, a safety assessment of combustion and flame stability during individual process conditions and of the shutdown limits of the combustion plant has to be carried out and documented.

The combustion air must be free from aggressive compounds (e.g. Halogens). If the combustion air in the boiler room is contaminated, increased cleaning and servicing will be required. In this case ducted air intake is recommended.

The burner should only be used in enclosed rooms.

Improper use could:

- endanger the health and safety of the user or third parties,
- cause damage to the unit or other material assets.

2.2 When gas can be smelled

Avoid open flames and spark generation, for example:

- do not operate light switches,
- do not operate electronic equipment,
- do not use mobile telephones.
- ▶ Open doors and windows.
- ▶ Close gas isolating valve.
- ▶ Warn the inhabitants, do not ring door bells.
- ▶ Leave the building.
- ▶ Inform the heating contractor or gas supplier from outside of the building.

2.3 Safety measures

Safety relevant fault conditions must be eliminated immediately.

Components, which show increased wear and tear or whose design lifespan is or will be exceeded prior to the next service should be replaced as a precaution.

The design lifespan of the components is listed in the service plan [ch. 9.2].

2.3.1 Personal protective equipment (PPE)

Use the necessary personal protective equipment for all work.

2.3.2 Normal operation

- All labels on the unit must be kept in a legible condition.
- Stipulated settings, service and inspection work should be carried out at regular intervals.
- Only operate the unit with its cover closed.

2.3.3 Electrical work

For work carried out on live components:

- Observe the accident prevention instructions DGUV Regulation 3 and adhere to local directives,
- tools in accordance with EN 60900 should be used.

The device contains components, which could be damaged by electrostatic discharge (ESD).

When working on circuit boards and contacts:

- do not touch circuit boards or contacts,
- if necessary, take ESD protective measures.

2.3.4 Gas supply

- Only the gas supply company or an approved agent may carry out installation, alteration and maintenance work on gas appliances in buildings and properties.
- Pipework must be subject to a combined load and valve proving test and/or usability testing relative to the pressure range intended, e. g. DVGW-TRGI, worksheet G 600.
- Inform the gas supply company about the type and size of plant prior to installation.
- Local regulations and guidelines must be observed during installation, e. g. DVGW-TRGI, worksheet G 600; TRF Band 1 and Band 2.
- The gas supply pipework should be suitable for the type and quality of gas and should be designed in such a way that it is not possible for liquids to form, e. g. condensate. Observe vaporisation pressure and vaporisation temperature of liquid petroleum gas.
- Use only tested and approved sealing materials, whilst observing all process information.
- Re-commission the appliance when changing to a different type of gas. Changing from LPG to Natural Gas and visa versa requires a conversion.
- Carry out soundness test after each service and fault rectification.

2.4 Alterations to the construction of the equipment

All conversions require written approval from Max Weishaupt GmbH.

- No additional components may be fitted, which have not been tested for use with the equipment.
- Do not use combustion chamber inserts, which hinder flame burnout.
- Use only original Weishaupt replacement parts.

2.5 Noise emission

The noise emissions are determined by the acoustic behaviour of all components fitted to the combustion system.

Prolonged exposure to high noise levels can lead to loss of hearing. Provide operating personnel with protective equipment.

Noise emissions can further be reduced with a sound attenuator.

2.6 Disposal

Dispose of all materials and components in a safe and environmentally friendly way at an authorised location. Observe local regulations.

3 Product description

3 Product description

3.1 Type key

Example: WG5N/-1A LN

Type


| | |
|---|---|
| W | Series: Compact burner |
| G | Fuel: Gas |
| 5 | Size |
| N | N: Natural Gas F: Liquid Petroleum Gas |
| 1 | Ratings size |
| A | Construction |

Version

| | |
|----|---------------------------------|
| LN | Mixing head: LowNO _x |
|----|---------------------------------|

3.2 Serial number

The serial number on the name plate identifies the product. This is required by Weishaupt's customer service department.



① Name plate

Ser.No. _____

3.3 Function

3.3.1 Air supply

Air damper

The air damper regulates the air quantity required for combustion. The air damper position is set using a setting screw on the air damper or the actuator (optional).

At burner shutdown the the actuator (optional) automatically closes the air damper. At burner shutdown the air dampers close automatically.

Fan wheel

The fan wheel supplies the air from the air intake housing to the combustion head.

Diffuser

The air gap between flame tube and diffuser is adjusted by positioning the diffuser. This adjusts the mixing pressure and the air quantity required for combustion.

Air pressure switch

The air pressure switch monitors the fan pressure. If the fan pressure is insufficient, the combustion manager initiates a lockout.

3 Product description

3.3.2 Gas supply

Gas isolating valve ①

The gas isolating valve opens and shuts off the gas supply.

Multifunction assembly ⑧

The multifunction assembly contains:

| | |
|----------------------|--|
| Gas filter ② | The gas filter protects the gas valve train from foreign particles. |
| Double gas valve ④ | The double gas valve opens and shuts off the gas supply. |
| Pressure regulator ③ | The pressure regulator reduces the connection pressure and ensures a constant setting pressure. Using setting screws, the gas quantity for ignition gas (A) and full load (B) can be set separately. |

Low gas pressure switch ⑦

The low gas pressure switch monitors the gas connection pressure. If the preset pressure is not achieved, the combustion manager initiates a low gas programme.

In the low gas programme the combustion manager interrupts burner start and burner operation. Following a low gas waiting time of 10 minutes an automatic re-start is initiated.


FRS pressure regulator ⑤ (optional)

Only required for a connection pressure > 50 ... 300 mbar.

The pressure regulator reduces the connection pressure to the permissible inlet pressure of the multifunction assembly.

High gas pressure switch ⑥ (optional)

The high gas pressure switch monitors the setting pressure. If the setting pressure exceeds the value set, the combustion manager initiates a controlled shutdown.



3.3.3 Electrical components

Combustion Manager

The combustion manager W-FM is the control unit of the burner.
It controls the sequence of operation and monitors the flame.

Burner motor

The burner motor drives the fan wheel.

Ignition unit

The electronic ignition unit creates a spark at the electrode, which ignites the fuel/air mixture.

Ionisation electrode

The combustion manager monitors the flame signal via the ionisation electrode.
If the flame signal becomes too weak, the combustion manager carries out a controlled shutdown.

3 Product description

3.3.4 Program sequence

Pre-purge without actuator

At heat demand, the burner motor starts after the initialisation time (T_I) has elapsed and the gas pressure switch has been activated.

The air pressure switch is activated during the pre-purge phase (T_V).

Pre-purge with actuator (optional)

At heat demand, the actuator starts after the initialisation time (T_I) has elapsed.

If the limit switch (S_2) is closed, the burner motor starts if the gas pressure switch has been activated.

The air pressure switch is activated during the pre-purge phase (T_V).

Ignition

Pre-ignition time (T_{VZ}) starts before the end of the pre-purge time (T_V).

Ignition starts.

Fuel release

Following pre-ignition time (T_{VZ}) the double gas valve (K_{32}) opens and releases the fuel.

Safety time

With fuel release, safety time (T_S) and post-ignition time (T_{NZ}) start.

The flame signal must be present within the safety time (T_S).

Operation


The combustion manager monitors the flame signal via the ionisation electrode.

Post-purge

If there is no longer a heat demand, the double gas valve (K_{32}) closes and stops the fuel supply.

Post-purge time (T_N) begins.

Following the post-purge time (T_N) the burner motor switches off.



- B1 Ionisation electrode
- B10 Air pressure switch
- B15 Temperature or pressure regulator
- B31 Low gas pressure switch
- F2 Temperature or pressure limiter
- K32 Double gas valve
- K33 External valve LPG
- M1 Burner motor
- M20 Air damper actuator (optional)
- P11 Control lamp operation (optional)
- S2 Actuator limit switch (optional)
- T1 Ignition unit
- ⁽¹⁾ Actuator start delay (optional)

- T_i Initialisation time: 1 s
- T_N Post-purge time: 1.2 s
- T_{NZ} Post-purge time: 2.4 s
- T_v Pre-purge time: 21.5 s
- T_s Safety time: 2.7 s
- T_{vz} Pre-ignition time: 1.9 s
- Voltage is applied
- Flame signal present
- Current path
- Start (orange)
- Ignition phase (flashing orange)
- Burner operation (green)

3 Product description

3.4 Technical data

3.4.1 Approval data

| | |
|-------------------|---|
| PIN (EU) 2016/426 | CE-0085AU0353 |
| Basic standards | EN 676:2008 Additional standards, see EU conformity certification. |

3.4.2 Electrical data

| | |
|---------------------------------|--------------------|
| Mains voltage / mains frequency | 230 V/50 Hz |
| Consumption at start | max 219 W |
| Consumption during operation | max 119 W |
| Power consumption | max 1.0 A |
| Internal unit fuse | T6.3H, IEC 127-2/5 |
| External fuse | max 16 AB |

3.4.3 Ambient conditions

| | |
|--|---------------------------|
| Temperature in operation | –15 ... +40 °C |
| Temperature during transport / storage | –20 ... +70 °C |
| relative humidity | max 80 %, no dew point |
| Installation elevation | max 2000 m ⁽¹⁾ |

⁽¹⁾ Consultation with Weishaupt is required for higher installation elevation.

3.4.4 Fuels

- Natural Gas E/LL
- Liquid Petroleum Gas B/P

3.4.5 Emissions

Flue gas

To EN 676 the burner complies with emission class 3.

The NO_x values are influenced by:

- combustion chamber dimensions
- flue gas system
- fuel
- combustion air (temperature and humidity)
- medium temperature

Combustion chamber dimensions, see Weishaupt Partner Portal / Documents and Applications / Online Applications / NO_x calculation for burners.

Sound levels

Dual number noise emission values

| | |
|---|-------------------------|
| Measured sound power level L _{WA} (re 1 pW) | 63 dB(A) ⁽¹⁾ |
| Uncertainty value K _{WA} | 4 dB(A) |
| Measured sound pressure level L _{pA} (re 20 µPa) | 58 dB(A) ⁽²⁾ |
| Uncertainty value K _{pA} | 4 dB(A) |

⁽¹⁾ Determined to ISO 9614-2.

⁽²⁾ Determined at 1 metre distance from the front of the burner.

The measured noise levels plus uncertainty values form the upper limit value, which could occur when measuring.

3 Product description

3.4.6 Rating

Combustion heat rating


| | |
|----------------------|----------------|
| Natural Gas | 12.5 ... 50 kW |
| Liquid Petroleum Gas | 12.5 ... 50 kW |
| Combustion head | WG5/1LN |

Capacity graph

Capacity graph to EN 676.

The capacity data given relates to an installation elevation of 0 m above sea level.
For installation elevations above 0 m a capacity reduction of approx. 1 % per 100 m applies.


A limited capacity graph is valid for ducted air intake.



- ① Combustion heat rating [kW]
- ② Combustion chamber pressure [mbar]

3.4.7 Dimensions


Burner



- ① 135 mm without combustion head extension
235 mm with combustion head extension (100 mm)
335 mm with combustion head extension (200 mm)

3 Product description

Gas valve train



| | Isolating valve | With thermal shut off device | Without thermal shut off device |
|---|------------------|------------------------------|---------------------------------|
| ① | Rp $\frac{1}{2}$ | approx. 310 mm | approx. 300 mm |
| ② | Rp $\frac{1}{2}$ | approx. 280 mm | approx. 270 mm |
| ③ | Rp $\frac{1}{2}$ | approx. 510 mm | approx. 500 mm |
| ④ | Rp $\frac{1}{2}$ | approx. 480 mm | approx. 470 mm |

3.4.8 Weight

approx. 12 kg

4 Installation

4.1 Installation conditions

Burner type and capacity graph

Burner and heat exchanger must be matched.

- Check burner type and burner capacity.

Installation location

- Prior to installation ensure that:
 - sufficient space is available for normal and service position [ch. 3.4.7],
 - sufficient combustion air is available, if necessary install ducted air intake,


Prepare heat exchanger

The refractory ③ must not protrude beyond the front edge of the combustion head. The refractory can take a conical shape (min 60°).

Refractory may not be required on boilers with water-cooled front, unless the manufacturer gives other instructions.

Following installation, the aperture ④ between flame tube and refractory should be filled with flame-proof, resilient insulating material. Do not make solid.

Heat exchangers with deep refractories or thick doors, or heat exchangers with reverse flame combustion chambers may require a combustion head extension. Head extensions of 100 and 200 mm are available. Dimension ② then changes according to the head extension used.



- ① Flange gasket
- ② 135 mm
- ③ Refractory
- ④ Aperture

4 Installation

4.2 Burner installation




Only valid in Switzerland

When installing and operating the regulations of SVGW, VKF, local and Cantonal regulations and the EKAS guideline (LPG Guideline Part 2) must be observed.




The burner in its standard version is designed for valve train connection from the right. For gas valve train connection from the left the burner has to be installed rotated by 180°. This does not require conversion measures.

- ▶ Remove burner flange ① from burner housing.
- ▶ Fit flange gasket ② and burner flange ① to the heat exchanger using screws ③.
- ▶ The aperture between combustion head and refractory should be filled with flame-proof, resilient insulating material (do not make solid).



- ▶ Mount burner with screws ① to burner flange.



- ▶ Check setting of ignition and ionisation electrode [ch. 9.5].

5 Installation

5.1 Gas supply



Risk of explosion due to leaking gas

Gas leaks can lead to a build-up of explosive gas/air mixture. With an ignition source present this can result in an explosion.

- ▶ Install gas supply with care.
- ▶ Observe all safety instructions.

Only an approved gas installer may carry out the gas side connection. Observe local regulations.

The following should be obtained from the gas supply company:

- Type of gas
- Gas connection pressure.
- Maximum CO₂ content in the flue gas.
- Calorific value in normal condition [kWh/m³].

Observe maximum permissible pressure of all components of the gas valve train.


- ▶ Close all fuel shut off devices prior to commencing work and protect from accidental re-opening.

General installation instructions

- Install manually operated shut off device (gas isolating valve) in the supply.
- Ensure correct mounting alignment and cleanliness of sealing surfaces.
- Mount valve train free of vibration. It must not be allowed to swing. Suitable supports should be fitted.
- Mount gas valve train free of stresses.
- The distance between burner and Multifunction assembly should be as small as possible. If the distance is too great, it is possible that a gas/air mixture is formed, which will influence burner start.
- Observe sequence and flow direction of gas valve train.
- If necessary, fit thermal shut off device (TAE) in front of the gas isolating valve.

Installation position

Multifunction assembly and pressure regulator (optional) can be installed with the axis standing vertical to lying horizontal.



5 Installation


5.1.1 Installing the gas valve train

Installing the valve train from the right

- ▶ Remove protective foil from gas connection flange.
- ▶ Mount gas valve train free from stresses. Do not compensate for installation errors by over-tightening the flange screws.
- ▶ Ensure correct alignment of flange seals.
- ▶ Tighten screws evenly diagonally across.



No additional sealant is required if the thread is coated in blue.



A Connection pressure ≤ 50 mbar


B Connection pressure $> 50 \dots 300$ mbar

Installing the gas valve train from the left

To fit the gas valve train to the burner from the left, the burner has to be installed rotated by 180° . This does not require any additional conversion measures.

- ▶ Continue installation in the same way as for "Mount gas valve train from the right".

Accessories



① High gas pressure switch with mechanical interlock (B33)

5 Installation

5.1.2 Carry out soundness test of gas supply line and vent

Only the gas supply company or a contract installation company may carry out a soundness test and vent the gas line.

5.2 Electrical connection



Risk of electric shock


Working on the device when voltage is applied can lead to electric shock.

- ▶ Isolate the device from the power supply prior to starting any work.
- ▶ Safeguard against accidental restart.

The electrical connection must only be carried out by qualified electricians. Observe local regulations.

Observe wiring diagram [ch. 11.1].

- ▶ Plug in plug for gas pressure switch ② and double gas valve ③ and secure with screws.
- ▶ Check polarity and wiring of 7 pole connection plug ①.
- ▶ Plug in connection plug ①.



With remote reset, install connection line separately. Do not exceed maximum cable length of 10 metres.

6 Operation

6 Operation

6.1 Operating panel




Damage to the combustion manager due to incorrect operation

Excessive pressure applied to the illuminated push button can damage the combustion manager.

- Only lightly press illuminated push button.

The illuminated push button on the combustion manager has the following functions:

- display operating condition [ch. 6.2],
- display fault codes [ch. 10.1.2],
- reset burner lockout [ch. 10.1.2].



Re-starting the burner during burner operation:

- Press illuminated push button for 1 second.

6.2 Display

| Illuminated push button | Operating condition |
|-------------------------|------------------------------|
| orange | Start phase |
| Flashing orange | Ignition and pre-purge phase |
| Green | Operation |
| red | Fault [ch. 10] |

Additional flashing signals can be read off as fault code [ch. 10].

7 Commissioning

7.1 Prerequisite

Commissioning must only be carried out by qualified personnel.

Only correctly carried out commissioning ensures the operational safety.



Do not operate the burner outside of the capacity graph [ch. 3.4.6].

► Prior to commissioning ensure that:

- all assembly and installation work has been carried out correctly,
- sufficient combustion air is available, if necessary install ducted air intake
- the annulus between flame tube and heat exchanger is filled
- the heat exchanger is filled with medium
- the regulating, control and safety devices are functioning and set correctly
- the flue gas ducts are unimpeded
- a measuring point conforming to standards is available to measure the flue gas
- the heat exchanger and flue gas ducting up to the test point are sound (extraneous air influences the test results)
- the operating instructions of the heat exchanger are complied with
- a heat demand is available

Additional system-related tests could be necessary. Please observe the operating guidelines for the individual components.

On installations with process equipment, the conditions for safe operation and commissioning must be met, see worksheet 8-1 (Print No. 831880xx).

7 Commissioning


7.1.1 Connect measuring devices

Measuring device for ionisation current

- Remove ionisation cable from the plug coupling.
- Connect current measuring device in series.


Ionisation current

| | |
|---------------------------------|------------------------|
| Extraneous light detection from | 0.8 μA |
| Minimum ionisation current | 1.5 μA |
| Recommended ionisation current | 5 ... 20 μA |



Pressure measuring device for mixing pressure

- Open pressure test point for mixing pressure ① and connect pressure measuring device.



7.1.2 Check gas connection pressure

Minimum connection pressure



Add the combustion chamber pressure in mbar to the minimum connection pressure. The connection pressure should not fall below 15 mbar.

Maximum connection pressure

Maximum connection pressure into isolating valve is 300 mbar.

For connection pressures > 50 mbar, an FRS pressure regulator must be installed upstream.

Check connection pressure



Risk of explosion due to excess gas supply pressure

Exceeding the maximum connection pressure (see name plate) can damage the gas valve train and lead to an explosion.

Max. connection pressure see name plate.

► Check gas connection pressure


- Connect pressure measuring device to test point ①.
- Slowly open isolating valve whilst observing the pressure increase.

If the connection pressure exceeds the max. connection pressure:

- Immediately close isolating valve.
- Do not start plant.
- Notify system operator.

If the connection pressure does not maintain the min. connection pressure:

- Do not start plant.
- Notify system operator.



A Connection pressure \leq 50 mbar

B Connection pressure > 50 ... 300 mbar

7 Commissioning

7.1.3 Check soundness of gas valve train

Carry out soundness test:

- prior to commissioning,
- after all service and maintenance work.

| | First test phase | Second test phase |
|--|---------------------|--------------------|
| Test pressure | 100 mbar \pm 10 % | 50 mbar \pm 10 % |
| Waiting time for pressure equalisation | 5 minutes | 5 minutes |
| Test time | 5 minutes | 5 minutes |
| Permissible pressure loss | 1 mbar | 5 mbar |

First test phase


In the first phase the valve train section from the gas isolating valve up to the first valve of the multifunction assembly is tested.

- ▶ Switch off burner.
- ▶ Close gas isolating valve.
- ▶ Connect test equipment.
- ▶ Open test point between valve 1 and valve 2.
- ▶ Carry out test to table.

Second test phase

In the second phase the interspace in the multifunction assembly is tested.

- ▶ Connect test equipment.
- ▶ Carry out test to table.



① First test phase

② Second test phase

A Connection pressure \leq 50 mbar

B Connection pressure $>$ 50 ... 300 mbar

Third test phase

In the third phase the valve train section from multifunction assembly outlet up to the sealing point of the burner is tested. The test phase can only be carried out during or after burner commissioning.


A leak detecting spray or electronic gas detector should be used for testing.



Use only leak detecting foam solutions, which do not cause corrosion, see DVGW-TRGI, worksheet G 600.

- ▶ Check all components, intersections and test points of the gas valve train between multifunction assembly and burner.
- ▶ Document result of the soundness test on the engineers report.


Test points



- ① Pressure into valve 1
- ② Pressure between valve 1 and valve 2
- ③ Pressure after valve 2

7.1.4 Purging the gas valve train

- ▶ Open test point into valve 1 [ch. 7.1.3].
- ▶ Connect an approved vent hose to the test point.
- ▶ Vent hose must lead to atmosphere.
- ▶ Slowly open gas isolating valve.
- ✓ The gas/air mixture in the valve train vents via the hose to safe atmosphere.
- ▶ Close gas isolating valve.
- ▶ Remove vent hose and immediately close test point.
- ▶ Use a test burner to ensure no air is present in the valve train.



7 Commissioning

7.1.5 Preset pressure regulator

Determine setting pressure



An additional pressure regulator is required for connection pressure > 50 mbar.
Set FRS pressure regulator [ch. 7.1.6].



Add the combustion chamber pressure in mbar to the setting pressure.

► Determine setting pressure and dimension ① and ③ from table and note down.

The details given for calorific value H_i relate to 0 °C and 1013 mbar.

The table values have been calculated under ideal conditions. The values are therefore guide values for basic settings.

| Full load [kW] | Setting pres- sure [mbar] | Full load setting Dimension ① [mm] | Ignition load setting Dimension ③ [mm] | |
|--|---------------------------------|---------------------------------------|---|---------|
| | | | Connection pressure ⁽¹⁾ | |
| | | | 20 mbar | 50 mbar |
| Natural Gas E: $H_i = 10.35 \text{ kWh/m}^3$, $d = 0.606$ | | | | |
| 12.5 | 3.0 | 13.0 | 16.0 | 14.0 |
| 15.0 | 3.2 | 14.0 | 16.0 | 15.0 |
| 17.5 | 3.4 | 14.5 | 17.0 | 15.5 |
| 20.0 | 3.6 | 15.0 | 17.0 | 16.0 |
| 22.5 | 4.0 | 16.0 | 17.5 | 16.5 |
| 25.0 | 4.2 | 18.0 | 18.0 | 16.5 |
| 27.5 | 5.0 | 18.0 | 18.5 | 17.0 |
| 30.0 | 5.5 | 18.0 | 18.5 | 17.0 |
| 32.5 | 6.3 | 18.0 | 18.5 | 17.0 |
| 35.0 | 6.6 | 22.0 | 19.0 | 18.0 |
| 37.5 | 7.2 | 22.0 | 19.0 | 18.0 |
| 40.0 | 7.9 | 22.0 | 19.0 | 18.0 |
| 42.5 | 8.5 | 22.0 | 19.0 | 18.0 |
| 45.0 | 9.3 | 22.0 | 19.0 | 18.0 |
| 47.5 | 10.2 | 22.0 | 19.0 | 18.0 |
| 50.0 | 11.1 | 22.0 | 19.0 | 18.0 |

⁽¹⁾With connection pressures between 20 and 50 mbar, the value of dimension ③ must be interpolated.

| Full load [kW] | Setting pres- sure [mbar] | Full load setting Dimension ① [mm] | Ignition load setting Dimension ③ [mm] | |
|---|---------------------------------|---------------------------------------|---|---------|
| | | | Connection pressure ⁽¹⁾ | |
| | | | 20 mbar | 50 mbar |
| Natural Gas LL: $H_i = 8.83 \text{ kWh/m}^3$, $d = 0.641$ | | | | |
| 12.5 | 3.4 | 13.5 | 17.5 | 16.5 |
| 15.0 | 3.6 | 14.0 | 17.5 | 16.5 |
| 17.5 | 4.0 | 14.5 | 18.0 | 17.0 |
| 20.0 | 4.4 | 15.0 | 18.0 | 17.0 |
| 22.5 | 4.8 | 16.0 | 18.5 | 17.5 |
| 25.0 | 5.0 | 18.0 | 19.0 | 17.5 |
| 27.5 | 6.0 | 18.0 | 19.5 | 17.5 |
| 30.0 | 6.9 | 18.0 | 19.5 | 17.5 |
| 32.5 | 7.9 | 18.0 | 19.5 | 17.5 |
| 35.0 | 8.3 | 22.0 | 20.0 | 18.0 |
| 37.5 | 9.2 | 22.0 | 20.0 | 18.0 |
| 40.0 | 10.3 | 22.0 | 20.0 | 18.0 |
| 42.5 | 11.3 | 22.0 | 20.0 | 18.0 |
| 45.0 | 12.5 | 22.0 | 20.0 | 18.0 |
| 47.5 | 13.6 | 22.0 | 20.0 | 18.0 |
| 50.0 | 14.6 | 22.0 | 20.0 | 18.0 |
| Liquid Petroleum Gas: $H_i = 25.89 \text{ kWh/m}^3$, $d = 1.555$ The selection is calculated for Propane, it can however, also be used for Butane. | | | | |
| 12.5 | 3.0 | 12.5 | 16.0 | 13.5 |
| 15.0 | 3.2 | 12.8 | 16.0 | 14.0 |
| 17.5 | 3.4 | 13.0 | 16.0 | 14.0 |
| 20.0 | 3.6 | 13.5 | 16.5 | 14.5 |
| 22.5 | 3.8 | 14.0 | 16.5 | 15.0 |
| 25.0 | 4.2 | 14.5 | 17.0 | 15.5 |
| 27.5 | 4.5 | 15.0 | 17.0 | 15.5 |
| 30.0 | 4.7 | 16.0 | 17.0 | 16.0 |
| 32.5 | 5.0 | 16.0 | 17.0 | 16.0 |
| 35.0 | 5.2 | 22.0 | 17.5 | 16.5 |
| 37.5 | 5.6 | 22.0 | 17.5 | 16.5 |
| 40.0 | 6.0 | 22.0 | 17.5 | 16.5 |
| 42.5 | 6.5 | 22.0 | 17.5 | 16.5 |
| 45.0 | 7.1 | 22.0 | 17.5 | 16.5 |
| 47.5 | 7.7 | 22.0 | 17.5 | 16.5 |
| 50.0 | 8.1 | 22.0 | 17.5 | 16.5 |

⁽¹⁾With connection pressures between 20 and 50 mbar, the value of dimension ③ must be interpolated.

7 Commissioning

Pre-set setting screws

Pre-set setting pressure determined and dimension ① and ③ on the multifunction assembly.

Example


| Burner rating re-quired | Type of Gas | Combustion chamber pressure | Gas connection pressure |
|-------------------------|---------------|-----------------------------|-------------------------|
| 30 kW | Natural Gas E | 0.2 mbar | 20 mbar |

| Setting pressure determined + combustion chamber pressure | Full load setting | Ignition load setting (20 mbar) |
|---|-------------------|---------------------------------|
| 5.5 mbar + 0.2 mbar | 18 mm | 18.5 mm |

► Change the position of the setting screws on the W-MF based on the factory settings.

| Setting pressure ② | Full load setting ① | Ignition load setting (20 mbar) ③ |
|---|---|---|
| $\frac{3}{4}$  | 2 x  | 1 x  |

| | one rotation changes | Factory presetting |
|-------------------------|----------------------|--------------------|
| Full load setting ① | 0.5 mbar | 19 mm |
| Setting pressure ② | 1.5 mbar | 5 mbar |
| Ignition load setting ③ | 0.5 mbar | 19 mm |




7.1.6 Set FRS pressure regulator (optional)

Only required for a connection pressure > 50 ... 300 mbar.

If the spring used in the pressure regulator is orange (5 ... 20 mbar):

- ▶ Turn setting screws clockwise (+) to its stop.
- ✓ The setting pressure is reduced to 20 mbar.
- ▶ Select the ignition load setting for a connection pressure of 20 mbar from the table.

Do not change this setting on the pressure regulator.



7.1.7 Setting values

Set mixing head relative to the combustion heat rating required. For this, the diffuser setting and the air damper setting should be matched.

Determine diffuser setting and air damper setting




Do not operate the burner outside of the capacity graph [ch. 3.4.6].

- Determine the diffuser setting (dimension X) and air damper setting required from the diagram and note down.

Example


| | |
|--------------------------------|--------|
| Burner capacity required | 40 kW |
| Diffuser setting (dimension X) | 6.5 mm |
| Air damper setting | 6.2 |

Diffuser default settings



- ① Combustion heat rating [kW]
- ② Diffuser settings (dimension X) [mm]

Air damper default settings




- ① Combustion heat rating [kW]
- ② Air damper setting

Set diffuser


With dimension $X = 0\text{mm}$ the indicating bolt is flush with nozzle assembly cover.

- Turn screw ①, until dimension X equals the value determined.



Set air damper

- Turn setting screw ① until the scale shows the value determined.




- A Manual adjustment
- B Actuator (optional)

7 Commissioning

Determine mixing pressure

- Determine the mixing pressure required for the preset combustion heat rating from the diagram and note down.



- ① Combustion heat rating [kW]
- ② Mixing pressure [mbar]
- Guide values, which could vary depend. on comb. chamber resistance.

7.1.8 Preset gas and air pressure switch

The presetting of the pressure switches is only valid during commissioning. Once commissioning has been completed the pressure switches must be set correctly [ch. 7.3].

| | |
|-------------------------------------|--------------------------------|
| Air pressure switch | approx. 2 mbar |
| Low gas pressure switch | 5 mbar |
| High gas pressure switch (optional) | approx. twice control pressure |

7.2 Adjusting the burner



Risk of electric shock

Touching the ignition device can lead to electric shock.

- ▶ Do not touch ignition device during the ignition process.


- ▶ During commissioning check:
 - flame signal [ch. 7.1.1],
 - mixing pressure [ch. 7.1.7].

1. Check sequence of operation

- ▶ Open gas isolating valve.
- ✓ Pressure in gas valve train increases.
- ▶ Close isolating valve.
- ▶ Switch on voltage supply.
- ✓ Illuminated push button lights up red.
- ▶ Press illuminated push button for 1 second.
- ✓ Burner starts in accordance with the programme sequence [ch. 3.3.4].
- ▶ Check sequence of operation:
 - Valves open.
 - Gas pressure switch reacts.
 - Burner start is interrupted.
 - Low gas programme starts, the illuminated button flashes red.

2. Adjust setting pressure

- ▶ Open test point for setting pressure and connect pressure measuring device.



- ▶ Open gas isolating valve.
- ▶ Press illuminated push button of combustion manager
- ✓ Low gas program is reset.
- ✓ Burner starts in accordance with the programme sequence.
- ▶ Preset setting pressure determined at multifunction assembly [ch. 7.1.5].

3. Adjust combustion

When adjusting, the ratings data given by the boiler manufacturer and the capacity graph of the burner should be observed [ch. 3.4.6].

- ▶ Check CO content of combustion and if necessary adjust combustion values via air damper and/or diffuser. Observe mixing pressure while doing so.
- ▶ Calculate gas throughput (operating volume V_B) required [ch. 7.6].
- ▶ Optimise setting pressure until gas throughput (V_B) is achieved.
- ▶ Check combustion values
- ▶ Determine combustion limit and set excess air via air damper and/or diffuser [ch. 7.5].
- ▶ Determine gas throughput once more and adjust if necessary.
- ▶ Re-set excess air.

4. Check start behaviour


- ▶ Switch off and restart burner.
- ▶ Check start behaviour and if necessary correct ignition position.

If the ignition load setting has been adjusted, the controller function of the multifunction assembly must be checked:

- ▶ De-energise setting pressure ①, turn towards Minus (–).
- ✓ Setting pressure drops by approx. 1 mbar.
- ▶ Set the setting pressure determined at the multifunction assembly and check start behaviour.

If the measured setting pressure does not decrease by approx. 1 mbar, the controller is overloaded and does not function:

- ▶ Turn the ignition load setting ② towards Minus (–), until the measured setting pressure decreases by approx. 1 mbar.
- ▶ Set the setting pressure determined at the multifunction assembly and check start behaviour.



7.3 Set pressure switches

7.3.1 Set gas pressure switch

Set low gas pressure switch

The switch point must be checked and if necessary adjusted during commissioning.


- ▶ Connect pressure measuring device to test point ① of the gas pressure switch.
- ▶ Start the burner.
- ▶ Slowly close gas isolating valve until either:
 - the O₂ content in the flue gas increases to above 7 %,
 - the flame stability considerably worsens,
 - the CO content increases,
 - or the gas flow pressure drops to 50 %.
- ▶ Determine gas pressure.
- ▶ Slowly open gas isolating valve.
- ▶ Set the pressure determined as switch point at the setting cam ②.

Check switch point

- ▶ Restart the burner.
- ▶ Slowly close gas isolating valve.
- ✓ If the low gas program starts, the gas pressure switch has been set correctly.
- ✓ If a lockout occurs or if the combustion reaches a critical condition, the low gas pressure switch reacts too late.

If lockout occurs:

- ▶ Increase switch point at setting cam ②.
- ▶ Slowly open gas isolating valve.
- ▶ Re-check switch point.



Set (optional) high gas pressure switch

- ▶ Set high gas pressure switch to $1.3 \times P_{\text{Gas full load}}$ (flow pressure at full load).

7.3.2 Set air pressure switch


The switch point must be checked and if necessary adjusted during commissioning.

- ▶ Connect pressure measuring device for differential pressure measurement.
- ▶ Start the burner.
- ▶ Determine differential pressure.
- ▶ Calculate switch point (80 % of differential pressure).
- ▶ Undo screw ②.
- ▶ Set the switch point determined at the setting cam ①.
- ▶ Tighten screw ②.

Example

| | |
|---|--|
| Differential pressure | 3 mbar |
| Switch point air pressure switch (80 %) | $3 \text{ mbar} \times 0.8 = 2.4 \text{ mbar}$ |

Site specific influences on the air pressure, (e.g. by the flue gas system, heat exchanger, installation location or air supply) may make it necessary to vary the setting of the air pressure switch.



7 Commissioning

7.4 Concluding work

- ▶ Check control and safety devices.
- ▶ Remove gas pressure measuring devices and close all test points.
- ▶ Conclude valve proving of gas valve train (third test phase) [ch. 7.1.3].
- ▶ Enter combustion values and settings in the commissioning record and/or test sheet.
- ▶ Mount cover on burner.
- ▶ Inform the operator about the use of the equipment.
- ▶ Hand the installation and operating manual to the operator and inform him that this should be kept with the appliance.
- ▶ Point out to operator that the installation should be serviced annually.

7.5 Check combustion

Determine excess air

- ▶ Slowly close air damper(s) in the relevant operating point, until the combustion limit is reached (CO content approx. 100 ppm).
- ▶ Measure and document O₂ content.
- ▶ Read air number (λ).

Increase air number to ensure sufficient excess air:

- by 0.15 ... 0.2 (equates to 15 ... 20 % excess air),
- by more than 0.2 for more difficult conditions, such as:
 - dirty combustion air,
 - fluctuating intake temperature,
 - fluctuating chimney draught.

Example

$$\lambda + 0.15 = \lambda^*$$

- ▶ Set air number (λ*), do not exceed CO content of 50 ppm.
- ▶ Measure and document O₂ content.

Check flue gas temperature

- ▶ Check flue gas temperature.
- ▶ Ensure that the flue gas temperature complies with the data provided by the boiler manufacturer.
- ▶ If necessary adjust flue gas temperature, e.g.:
 - Increase burner capacity to avoid condensation in the flue gas ducts, except on condensing units.
 - Reduce burner capacity to improve efficiency.
 - Adjust heat exchanger to the data provided by the manufacturer.

Determine flue gas losses

- ▶ Measure combustion air temperature (t_L) near the air damper(s).
- ▶ Measure oxygen content (O₂) and flue gas temperature (t_A) at the same time at one point.
- ▶ Determine flue gas losses using the following formula:

$$q_A = (t_A - t_L) \cdot \left(\frac{A_2}{21 - O_2} + B \right)$$

q_A Flue gas losses [%]

t_A Flue gas temperature [°C]

t_L Combustion air temperature [°C]

O₂ Volumetric content of oxygen in dry flue gas [%]

| Fuel factors | Natural Gas | Liquid Petroleum Gas |
|----------------|-------------|----------------------|
| A ₂ | 0,66 | 0,63 |
| B | 0.009 | 0.008 |

7 Commissioning

7.6 Calculate gas throughput

| Formula symbol | Explanation | Example values |
|----------------|---|-----------------------------|
| V_B | Operating volume [m³/h] Volume measured at gas meter at current pressure and temperature (gas throughput). | – |
| V_N | Standard volume [m³/h] Volume gained by gas at 1013 mbar and 0 °C. | – |
| f | Conversion factor | – |
| Q_N | Heat rating [kW] | 50 kW |
| η | Boiler efficiency (e. g. 92 % \pm 0.92) | 0,92 |
| H_i | Calorific value [kWh/m³] at 0 °C and 1013 mbar | 10.35 kW/m³ (Natural Gas E) |
| t_{Gas} | Gas temperature at gas meter [°C] | 10 °C |
| P_{Gas} | Pressure at gas meter [mbar] | 25 mbar |
| P_{Baro} | Barometric air pressure [mbar], see table | 500 m \pm 955 mbar |
| V_G | Gas throughput determined at gas meter | 0.18 m³ |
| T_M | Measuring time [seconds] | 120 seconds |

Calculate normal volume

- Calculate the normal volume (V_N) using the following formula.

$$V_N = \frac{Q_N}{\eta \cdot H_i} \quad V_N = \frac{50 \text{ kW}}{0,92 \cdot 10.35 \text{ kW/m}^3} = 5.25 \text{ m}^3/\text{h}$$

Calculate conversion factor

- Determine gas temperature (t_{Gas}) and pressure (P_{Gas}) at gas meter.
► Determine barometric air pressure (P_{Baro}) from table.

| Height above sea level [m] | 0 | 100 | 200 | 300 | 400 | 500 | 600 | 700 | 800 | 900 | 1000 | 1100 | 1200 | 1300 |
|----------------------------|------|------|-----|-----|-----|-----|-----|-----|-----|-----|------|------|------|------|
| P_{Baro} [mbar] | 1013 | 1001 | 990 | 978 | 966 | 955 | 943 | 932 | 921 | 910 | 899 | 888 | 877 | 866 |

- Calculate conversion factor (f) using the following formula.

$$f = \frac{P_{Baro} + P_{Gas}}{1013} \cdot \frac{273}{273 + t_{Gas}} \quad f = \frac{955 + 25}{1013} \cdot \frac{273}{273 + 10} = 0.933$$

Calculate operating volume (gas throughput) required

$$V_B = \frac{V_N}{f} \quad V_B = \frac{5.25 \text{ m}^3/\text{h}}{0.933} = 5.63 \text{ m}^3/\text{h}$$

Determine current operating volume (gas throughput)

- Measure gas throughput (V_G) at gas meter, measuring time (T_M) should be a minimum of 60 seconds.
► Calculate operating volume (V_B) using the following formula.

$$V_B = \frac{3600 \cdot V_G}{T_M} \quad V_B = \frac{3600 \cdot 0.18 \text{ m}^3}{120 \text{ s}} = 5.4 \text{ m}^3/\text{h}$$

8 Shutdown

For breaks in operation:

- ▶ Switch off burner.
- ▶ Close fuel shut off devices.

9 Servicing

9.1 Notes on servicing



Risk of explosion due to leaking gas

Improper service work can lead to escaping gas and explosion.

- ▶ Close fuel shut off devices prior to starting work.
- ▶ Care should be taken when dismantling and assembling gas carrying components.
- ▶ Close the screws on the test points ensuring the tests points are sealed.



Risk of electric shock

Working on the device when voltage is applied can lead to electric shock.

- ▶ Isolate the device from the power supply prior to starting any work.
- ▶ Safeguard against accidental restart.



Danger of getting burned on hot components

Hot components can lead to burns.

- ▶ Allow components to cool.

Servicing must only be carried out by qualified personnel. The combustion plant should be serviced annually. Depending on site conditions more frequent checks may be required.

Components, which show increased wear and tear or whose design lifespan is or will be exceeded prior to the next service should be replaced as a precaution.

The design lifespan of the components is listed in the service plan [ch. 9.2].



Weishaupt recommends a service contract is entered into to ensure regular inspections.

The following components must only be replaced and must not be repaired:

- combustion manager
- flame sensor
- actuator
- multifunction assembly
- pressure regulator
- pressure switch

Prior to every servicing

- ▶ Inform the operator about the extent of service work to be carried out.
- ▶ Switch off mains switch of installation and safeguard against accidental reactivation.
- ▶ Close fuel shut off devices.
- ▶ Remove cover.
- ▶ Unplug boiler control connection plug from combustion manager.

Following servicing



Risk of electric shock

Touching the ignition device can lead to electric shock.

- ▶ Do not touch ignition device during the ignition process.

-
- ▶ Check tightness of gas carrying components.
 - ▶ Check function of:
 - ignition,
 - flame monitoring,
 - gas carrying components (gas connection pressure and setting pressure),
 - pressure switch,
 - control and safety devices.
 - ▶ Check combustion values, if necessary re-adjust the burner.
 - ▶ Enter combustion values and settings in the commissioning record.
 - ▶ Refit cover.

9 Servicing

9.2 Service plan

| Components | Criteria / design lifespan ⁽¹⁾ | Service procedure |
|------------------------|--|---|
| Fan wheel | Soiling | ► Clean |
| | Damage | ► Replace |
| Air duct | Soiling | ► Clean |
| Air damper | Soiling | ► Clean |
| Air pressure switch | Switch point | ► Check |
| | 250 000 burner starts or 10 years ⁽²⁾ | ► Replace |
| Ignition cable | Damage | ► Replace |
| Ignition electrode | Soiling | ► Clean |
| | Damage/wear | ► Replace |
| Combustion Manager | 250 000 burner starts or 10 years ⁽²⁾ | ► Replace |
| Ionisation cable | Damage | ► Replace |
| Ionisation electrode | Soiling | ► Clean |
| | Damage/wear | ► Replace Recommendation: at least every 2 years |
| Flame tube/diffuser | Soiling | ► Clean |
| | Damage | ► Replace |
| Multifunction assembly | Function / soundness | ► Replace |
| | 250 000 burner starts or 10 years ⁽²⁾ | |
| Gas pressure regulator | Setting pressure | ► Check |
| | Function / soundness | ► Replace |
| | 15 years | ► Replace |
| Gas pressure switch | Switch point | ► Check |
| | 50 000 burner starts or 10 years ⁽²⁾ | ► Replace |

⁽¹⁾ The specified design lifespan applies for typical use in heating, hot water and steam systems as well as for thermal process systems to EN 746.

⁽²⁾ If a criterion is reached, carry out maintenance measures.

9.3 Removing and refitting mixing head


Observe notes on servicing [ch. 9.1].

Removing

- ▶ Unplug ionisation cable ③.
- ▶ Unplug ignition cable ②.
- ▶ Remove screws ④.
- ▶ Remove screw ⑤ and remove nozzle assembly cover ⑥.
- ▶ Push mixing head ① to the side and remove.

Refitting

- ▶ Refit mixing head in reverse order ensuring correct alignment of O ring ⑦.



9 Servicing

9.4 Set mixing head

Observe notes on servicing [ch. 9.1].

The distance between diffuser and flame tube front edge S1 can not be measured with the burner mounted. This is only possible indirectly with the mixing head removed, with dimension Lx.



Dimension Lx changes according to the combustion head extension used.


- ▶ Remove mixing head [ch. 9.3].
- ▶ Refit nozzle assembly cover to mixing head.
- ▶ Turn setting screw ① until it is flush with the nozzle assembly cover (dimension X = 0 mm).
- ▶ Check dimension Lx.

If the value measured deviates from dimension Lx:

- ▶ Undo screws ②.
- ▶ Adjust flame tube ③ until dimension Lx has been reached.
- ▶ Re-tighten screws ②.

If the screws ② have been loosened:


- ▶ Check position of electrodes and gas orifices ④.



9.5 Set ionisation and ignition electrodes

Observe notes on servicing [ch. 9.1].


- ▶ Remove mixing head [ch. 9.3].
- ▶ Undo screw ①.
- ▶ Set ignition electrode and re-tighten screw.
- ▶ Undo screw ②.
- ▶ Set ionisation electrode and re-tighten screw.



9.6 Service position

Observe notes on servicing [ch. 9.1].

- ▶ Unplug ionisation cable ④ and ignition cable ③.
- ▶ Remove screws ⑥.
- ▶ Remove screw ⑤ and remove nozzle assembly cover.
- ▶ If necessary unplug actuator plug.
- ▶ Hold housing cover and remove screws ①.
- ▶ Place housing cover into service position ②.



9 Servicing

9.7 Removing and refitting fan wheel


Observe notes on servicing [ch. 9.1].

Removing

- Place housing cover into service position [ch. 9.6].
- Remove grub screw ① and remove fan wheel.

Refitting


- Refit fan wheel in reverse order and
 - ensure correct alignment on the motor shaft ②,
 - screw in new grub screw ①,
 - turn fan wheel to ensure it moves freely.



9.8 Remove burner motor

Observe notes on servicing [ch. 9.1].

- Remove fan wheel [ch. 9.7].
- Unplug plug number 3 and 11.
- Disconnect + and - hoses.
- Undo screws ① and remove air pressure switch.
- Hold motor and remove screws ②.
- Remove motor.




9.9 Removing and refitting air regulator

Observe notes on servicing [ch. 9.1].

Removing

- ▶ Remove bolts ①.
- ▶ Remove burner from heat exchanger [ch. 4.2].
- ▶ If necessary unplug actuator plug.
- ▶ Remove bolts ②.
- ▶ Remove intake housing ⑤.
- ▶ Remove bolts ④.
- ▶ Remove air regulator ③.



Refitting

- ▶ Refit air regulator in reverse order.
- ▶ Carry out soundness test [ch. 7.1.3].

9 Servicing

9.10 Replacing coil on multifunction assembly

Observe notes on servicing [ch. 9.1].



Damage to the PCB due to electrostatic discharge (ESD)


PCB can be damaged by contact.

- ▶ Do not touch the PCB and its components.
- ▶ Deflect electrostatic energy from the body, for example by touching grounded metal objects.



Ensure correct voltage and solenoid number when replacing the solenoid coil.


- ▶ Loosen cover ①.
- ▶ Remove circuit board ② and if necessary replace.
- ▶ Replace solenoid coil ③.



9.11 Replacing the fuse

Observe notes on servicing [ch. 9.1].

- ▶ Remove all plugs from the combustion manager.
- ▶ Remove screws from the combustion manager.
- ▶ Remove combustion manager.
- ▶ Replace fuse (T6.3H, IEC 127-2/5).



10 Troubleshooting


10 Troubleshooting

10.1 Procedures for fault conditions

The combustion manager recognises irregularities of the burner and indicates these with the illuminated push button.

The following conditions can occur:

- illuminated push button off [ch. 10.1.1],
- illuminated push button red [ch. 10.1.2],
- illuminated push button flashes [ch. 10.1.3].



10.1.1 Illuminated push button off

The following faults may be corrected by the operator:

| Fault | Cause | Rectification |
|----------------------|--|--|
| Burner not operating | External fuse has tripped ⁽¹⁾ | ► Check fuse. |
| | Heating switch is set to Off | ► Switch on heating switch. |
| | Temperature limiter or pressure limiter on heat exchanger has triggered ⁽¹⁾ | ► Reset temperature limiter or pressure limiter on heat exchanger. |
| | Low water safety interlock on heat exchanger has triggered ⁽¹⁾ | ► Top up water. ► Reset low water safety interlock on heat exchanger. |
| | Temperature regulator or pressure regulator on heat exchanger has been set incorrectly | ► Adjust temperature regulator or pressure regulator on heat exchanger. |
| | Boiler or heating circuit control is not functioning or has not been set correctly | ► Check function and setting of boiler or heating circuit control. |

⁽¹⁾ Notify your heating contractor or Weishaupt Customer Service if the problem occurs repeatedly.

10.1.2 Illuminated push button red

A burner fault has occurred. The burner is in lockout. Prior to resetting, the error code can be called up and used to control the cause of the fault.

Read error code

Only 5 seconds after a fault occurred can it be analysed and read.

- ▶ Press illuminated push button for 5 seconds.
- ✓ Illuminated push button briefly lights up orange.
- ✓ Illuminated push button flashes red.
- ▶ Count between the flashing pauses and flashing signals and note down.
- ▶ Rectify cause of fault, see table.

Resetting



Damage resulting from incorrect fault repair

Incorrect fault repair can cause damage to the equipment and injure personnel.

- ▶ Do not carry out more than 2 lockout resets successively.
- ▶ Faults must be rectified by qualified personnel.

- ▶ Press illuminated push button for 1 second.
- ✓ Red signal extinguishes.
- ✓ Burner has been reset.

10 Troubleshooting

Error codes with lockout

The following faults must only be rectified by qualified personnel:

| Fault codes | Fault | Cause | Rectification |
|---|--|--|---|
| 2 x flashing No flame, end of safety time | No ignition | Ignition electrode set incor- rectly | ► Set ignition electrode [ch. 9.5] |
| | | Ignition electrode dirty or wet | ► Clean ignition electrode |
| | | Ceramic insulator defective | ► Replace ignition elec- trode. |
| | | Ignition cable defective | ► Replace ignition cable |
| | | Ignition unit defective | ► Replace ignition unit |
| | Double gas valve does not open | Cable defective | ► Check cable, if necessary replace |
| | | Coil defective | ► Replace coil [ch. 9.10] |
| | Combustion manager does not detect a flame signal | No ionisation current present or insufficient | ► Measure ionisation current [ch. 7.1.1] ► Set ionisation electrode [ch. 9.5] ► Check contact resistance (terminal, plug) ► Correct burner setting ► When using an un- earthed mains supply (control transformer) the pole which is to be used as neutral conductor must be earthed |
| | | Ionisation electrode worn | ► Replace ionisation elec- trode |
| | | Ionisation cable defective | ► Replace cable |
| Flashing 3 times Air pressure switch fault | Air pressure switch does not react | Hoses not attached tightly | ► Check hoses on air pres- sure switch |
| | | Air pressure switch set in- correctly | ► Set air pressure switch [ch. 7.3.2] |
| | | Cable defective | ► Check cable, if necessary replace |
| | | Air pressure switch defect- ive | ► Check air pressure switch, if necessary re- place |
| | Burner motor does not run | Capacitor defective | ► Replace capacitor |
| | | Cable defective | ► Check cable, if necessary replace |
| | | Burner motor defective | ► Check burner motor, if necessary replace |
| Flashing 4 times Flame simulation/ extraneous light | Flame signal prior to or after operation | Ionisation current present | Extraneous light detection from 0.8 µA ► Find and eliminate per- turbation |
| | | Ionisation electrode defect- ive | ► Check the ionisation electrode, replace if ne- cessary |

The following faults must only be rectified by qualified personnel:

| Fault codes | Fault | Cause | Rectification |
|--|------------------------------------|--------------------------------------|---|
| Flashing 7 times Flame failure during operation | Flame signal insufficient | Burner setting incorrect | ► Check burner setting ► Check flame signal |
| | | Ionisation electrode soiled | ► Clean ionisation electrode |
| | | Ionisation electrode set incorrectly | ► Set ionisation electrode [ch. 9.5] |
| | | Ionisation electrode defective | ► Check the ionisation electrode, replace if necessary |
| Flashing 8 times Gas pressure switch fault | Gas pressure switch does not react | Gas pressure switch set incorrectly | ► Set gas pressure switch [ch. 7.3.1] |
| | | Gas pressure switch defective | ► Check gas pressure switch, if necessary replace |
| Flashing 10 times Combustion manager fault | Burner does not start | Parameters have been changed | ► Reset burner [ch. 10.1.2] |
| | | Combustion manager defective | ► Reset burner [ch. 10.1.2], if fault reoccurs replace combustion manager |

10 Troubleshooting

10.1.3 Illuminated push button flashes

An irregularity is present. The burner does not go to lockout. Once the fault has been rectified, the error code ceases.

Error codes without lockout

The following faults must only be rectified by qualified personnel:

| Fault codes | Cause | Rectification |
|--------------------------------|--|--|
| Flashing green/red | Flame signal at heat demand | ► Find and eliminate perturbation |
| | Flame formation caused by leaking solenoid valve | ► Replace multifunction assembly |
| Flashing red/orange with pause | Excess voltage | ► Check voltage supply |
| Flashing orange/red | Low voltage | ► Check voltage supply |
| | Internal unit fuse (F7) faulty | ► Replace fuse [ch. 9.11] |
| | Combustion manager fault | ► Replace combustion manager |
| Flashing red | Bridging plug No. 2 is missing | ► Plug in bridging plug No. 2 |
| | Low gas | ► Check gas connection pressure ► Set gas pressure switch [ch. 7.3.1] ► Check gas pressure switch |
| orange, after 2 minutes red | Air pressure switch does not react | ► Set air pressure switch [ch. 7.3.2] ► Check air pressure switch ► With ducted air intake air pressure switch, check air supply |
| Flashing green | Burner operation with weak flame signal | Minimum ionisation current 1.5 µA ► Check burner setting |
| | Ionisation electrode soiled | ► Clean ionisation electrode |
| | Ionisation electrode defective | ► Replace ionisation electrode |
| Glimmering red | OCl mode activated (not used) | ► Press illuminated push button for more than 5 seconds ✓ Combustion manager changes to operating mode |

10.2 Operating problems

The following faults must only be rectified by qualified personnel:



| Observation | Cause | Rectification |
|--|------------------------------------|---|
| Poor start behaviour of burner | Mixing pressure too high | ► Reduce mixing pressure in ignition position |
| | Ignition electrode set incorrectly | ► Set ignition electrode [ch. 9.5] |
| | Mixing head set incorrectly | ► Set mixing head [ch. 9.4] |
| | Ignition load set incorrectly | ► Set ignition load [ch. 7.2] |
| Combustion pulsating or burner booming | Mixing head set incorrectly | ► Set mixing head [ch. 9.4] |
| | Incorrect combustion air quantity | ► Adjust burner |
| Stability problems | Mixing pressure too high | ► Decrease mixing pressure |

11 Technical documentation


11 Technical documentation

11.1 Wiring diagram

For special version observe wiring diagram supplied.



- C1 Motor capacitor
- F1 External fuse (max 16 AB)
- F2 Temperature or pressure limiter
- F7 Internal unit fuse (T6.3H, IEC 127-2/5)
- B10 Air pressure switch
- B31 Low gas pressure switch
- B15 Temperature or pressure regulator
- P6 Control lamp lockout (optional)
- P11 Control lamp operation (optional)
- M1 Burner motor
- M20 Air damper actuator (optional)
- S1 Operating switch
- ① Bridge for air regulator with manual adjustment



- | | |
|-------|--------------------------|
| B1 | Flame sensor |
| P11.1 | Hours counter (optional) |
| S3 | Remote reset (optional) |
| T1 | Ignition unit |
| K32 | Double gas valve |
| K33 | External valve LPG |
| ② | Bus interface (optional) |

11 Technical documentation

11.2 Conversion table unit of pressure

| Bar | Pascal | | | |
|----------|-----------|--------|-------|---------|
| | Pa | hPa | kPa | MPa |
| 0.1 mbar | 10 | 0.1 | 0,01 | 0.00001 |
| 1 mbar | 100 | 1 | 0.1 | 0.0001 |
| 10 mbar | 1 000 | 10 | 1 | 0.001 |
| 100 mbar | 10 000 | 100 | 10 | 0,01 |
| 1 bar | 100 000 | 1 000 | 100 | 0.1 |
| 10 bar | 1 000 000 | 10 000 | 1 000 | 1 |

11.3 Appliance categories

Labelling of gas and dual fuel burners to EN 676

EN 676, "Forced draught burners for gaseous fuels", is used for the implementation of the basic requirements of the directive (EU) 2016/426.

EN 676 stipulate the following appliance categories for forced draught gas burners under Point 4.4.9:

| | |
|---------|--|
| I2R | for Natural Gas |
| I3R | for Liquid Petroleum Gas |
| II2R/3R | for Natural Gas / Liquid Petroleum Gas |

The test gases listed under point 5.1.1, table 4 and the minimum test pressures determined and listed under point 5.1.2, table 5 are used to provide the evidence of service performance of the burner during type testing.

As -weishaupt- gas and dual fuel burners fulfil this requirement completely, the appliance category, as well as the test gases used with the permissible connection pressure range, are listed on the name plate when labelling the burner to point 6.2 . This clearly defines the suitability of the burner for use with second or third family gases.

On the basis of a type test report to ISO 17025 from an accredited test centre, the EU Type Testing Certificate to Directive (EU) 2016/426 also quotes the appliance category, the supply pressure and the country of destination.

EN 437, "Test gases - test pressures - appliance categories", describes the interrelationships and the special national characteristics relating to this subject in detail.

The following tables give an overview of the interrelationships between the R Categories and the nationally used appliance categories with their types of gas and connection pressures.

11 Technical documentation

Alternative appliance category to I2R

| Country of destination | Appliance category | Test gas | Connection pressure mbar |
|------------------------|--------------------|---------------|--------------------------|
| AL (Albania) | I2H | G 20 | 20 |
| AT (Austria) | I2H | G 20 | 20 |
| BA (Bosnia) | I2H | G 20 | 20 |
| BE (Belgium) | I2E+, I2N, I2E(R)B | G 20 + G 25 | Pressures 20 / 25 |
| BG (Bulgaria) | I2H | G 20 | 20 |
| BY (Belarus) | | | |
| CH (Switzerland) | I2H | G 20 | 20 |
| CY (Cyprus) | I2H | G 20 | 20 |
| CZ (Czech Republic) | I2H | G 20 | 20 |
| DE (Germany) | I2ELL, I2E, I2L | G 20 / G 25 | 20 |
| DK (Denmark) | I2H | G 20 | 20 |
| EE (Estonia) | I2H | G 20 | |
| ES (Spain) | I2H | G 20 | 20 |
| FI (Finland) | I2H | G 20 | 20 |
| FR (France) | I2Esi, I2E+, I2L | G 20 + G 25 | Pressures 20 / 25 |
| GB (United Kingdom) | I2H | G 20 | 20 |
| GR (Greece) | I2H | G 20 | 20 |
| HR (Croatia) | I2H | G 20 | 20 |
| HU (Hungary) | I2H | G 20 | 20 |
| IE (Ireland) | I2H | G 20 | 20 |
| IS (Iceland) | I2H | G 20 | 20 |
| IT (Italy) | I2H | G 20 | 20 |
| LT (Lithuania) | | | |
| LU (Luxembourg) | I2E | G 20 | 20 |
| LV (Latvia) | | | |
| MD (Moldova) | I2H | G 20 | 20 |
| MK (Macedonia) | I2H | G 20 | 20 |
| MT (Malta) | I2H | G 20 | 20 |
| NL (The Netherlands) | I2L, I2EK | G 25 | 25 |
| NO (Norway) | I2H | G 20 | 20 |
| PL (Poland) | I2E | G 20 / GZ 410 | 20 |
| PT (Portugal) | I2H | G 20 | 20 |
| RO (Romania) | I2H | G 20 | 20 |
| SE (Sweden) | I2H | G 20 | 20 |
| SI (Slovenia) | I2H | G 20 | 20 |
| SK (Slovakia) | I2H | G 20 | 20 |
| SRB (Serbia) | I2H | G 20 | 20 |
| TR (Turkey) | I2H | G 20 | 25 |
| UA (Ukraine) | I2H | G 20 | 20 |

Alternative appliance category to I3R

| Country of destination | Appliance category | Test gas | Connection pressure mbar |
|------------------------|----------------------|--------------|---|
| AL (Albania) | I3+, I3P, I3B | G 30 + G 31 | Pressures 28 - 30 / 37 |
| AT (Austria) | I3B/P, I3P | G 30 + G 31 | 50 |
| BA (Bosnia) | I3B/P | G 30 | 30 (28-30) |
| BE (Belgium) | I3+, I3P, I3B, I3B/P | G 30 + G 31 | Pressures 28 - 30 / 37 |
| BG (Bulgaria) | I3+, I3P, I3B | G 30 + G 31 | Pressures 28 - 30 / 37 |
| BY (Belarus) | | | |
| CH (Switzerland) | I3B/P, I3+, I3P | G 30 + G 31 | Pressures 28 - 30 / 37 |
| CY (Cyprus) | I3B/P, I3+, I3P, I3B | G 30 + G 31 | Pressures 28 - 30 / 37 |
| CZ (Czech Republic) | I3B/P, I3+, I3P | G 30 + G 31 | Pressures 28 - 30 / 37 |
| DE (Germany) | I3B/P, I3P | G 30 + G 31 | 50 |
| DK (Denmark) | I3B/P | G 30 + G 31 | 30 (28 - 30) |
| EE (Estonia) | I3B/P | G 30 | |
| ES (Spain) | I3+, I3P, I3B | G 30 + G 31 | Pressures 28 - 30 / 37 |
| FI (Finland) | I3B/P | G 30 + G 31 | 30 (28 - 30) |
| FR (France) | I3+, I3P, I3B | G 30 G 31 | Pressures 28 - 30 / 37 Pressures 112 / 148 |
| GB (United Kingdom) | I3+, I3P, I3B | G 30 + G 31 | Pressures 28 - 30 / 37 |
| GR (Greece) | I3B/P, I3+, I3P, I3B | G 30 + G 31 | Pressures 28 - 30 / 37 |
| HR (Croatia) | I3B/P, I3P | G 30 + G 31 | 50 |
| HU (Hungary) | I3B/P | G 30 + G 31 | 50 |
| IE (Ireland) | I3+, I3P, I3B | G 30 + G 31 | Pressures 28 - 30 / 37 |
| IS (Iceland) | I3B/P | | |
| IT (Italy) | I3B/P, I3+, I3P | G 30 + G 31 | Pressures 28 - 30 / 37 |
| LT (Lithuania) | | | |
| LU (Luxembourg) | I3B/P | G 30 | |
| LV (Latvia) | | | |
| MD (Moldova) | I3+, I3P, I3B | G 30 + G 31 | Pressures 28 - 30 / 37 |
| MK (Macedonia) | I3+, I3P, I3B | G 30 + G 31 | Pressures 28 - 30 / 37 |
| MT (Malta) | I3+, I3P, I3B | G 30 + G 31 | Pressures 28 - 30 / 37 |
| NL (The Netherlands) | I3B/P, I3P | G 30 + G 31 | 30 (28 - 30) |
| NO (Norway) | I3B/P | G 30 + G 31 | 30 (28 - 30) |
| PL (Poland) | I3B/P | G 30 | |
| PT (Portugal) | I3+, I3P, I3B | G 30 G 31 | Pressures 28 - 30 / 37 Pressures 50 / 67 |
| RO (Romania) | I3B/P | G 30 | |
| SE (Sweden) | I3B/P | G 30 + G 31 | 30 (28 - 30) |
| SI (Slovenia) | I3B/P | G 30 | 30 |
| SK (Slovakia) | I3B/P | G 30 | 30 |
| SRB (Serbia) | I3B/P, I3P | G 30 + G 31 | 20 |
| TR (Turkey) | I3B/P | G 30 + G 31 | 30 |
| UA (Ukraine) | I3B/P, I3P | G 30 + G 31 | 50 |

11 Technical documentation

Alternative appliance category to II2R/3R

| Country of destination | Appliance category | Test gas | Connection pressure mbar | Test gas | Connection pressure mbar |
|------------------------|---|------------|--------------------------|--------------|---|
| AL (Albania) | II2H3+, II2H3P | G 20 | 20 | G 31 | 30 |
| AT (Austria) | II2H3B/P, II2H3P | G 20 | 20 | G 30 + G 31 | 50 |
| BA (Bosnia) | II2H3B/P | G 20 | 20 | G 30 | |
| BE (Belgium) | II2E+3P, II2H3B/P | G 20, G 25 | Pressures 20 / 25 | G 30 + G 31 | Pressures 28 - 30 / 37 |
| BG (Bulgaria) | II2H3+, II2H3P | G 20 | 20 | G 30 + G 31 | Pressures 28 - 30 / 37 |
| BY (Belarus) | | | | | |
| CH (Switzerland) | II1a2H, II2H3B/P, II2H3+, II2H3P | G 20 | 20 | G 30 + G 31 | Pressures 28 - 30 / 37 |
| CY (Cyprus) | II2H3B/P, II2H3+, II2H3P | G 20 | 20 | G 30 + G 31 | Pressures 28 - 30 / 37 |
| CZ (Czech Republic) | II2H3B/P, II2H3+, II2H3P | G 20 | 20 | G 30 + G 31 | Pressures 28 - 30 / 37 |
| DE (Germany) | II2ELL3B/P, II2E3B/P | G 20 | 20 | G 30 + G 31 | 50 |
| DK (Denmark) | II1a2H, II2H3B/P | G 20 | G 20 | G 30 + G 31 | 30 |
| EE (Estonia) | II2H3B/P | G 20 | 20 | G 30 | 30 |
| ES (Spain) | II2H3P, II2H3+ | G 20 | 20 | G 30 + G 31 | Pressures 28 - 30 / 37 |
| FI (Finland) | II2H3B/P | G 20 | 20 | G 30 + G 31 | 30 (28 - 30) |
| FR (France) | II2E+3+, II2E+3P, II2Esi3B/P | G 20 | 20 | G 30 G 31 | Pressures 28 - 30 / 37 Pressures 112 / 148 |
| GB (United Kingdom) | II2H3+, II2H3P | G 20 | 20 | G 30 + G 31 | Pressures 28 - 30 / 37 |
| GR (Greece) | II2H3B/P, II2H3+, II2H3P | G 20 | 20 | G 30 + G 31 | Pressures 28 - 30 / 37 |
| HR (Croatia) | II2H3B/P | G 20 | 20 | G 30 + G 31 | 30 (28-30) |
| HU (Hungary) | II2H3B/P | G 20 | 20 | G 30 + G 31 | |
| IE (Ireland) | II2H3+, II2H3P | G 20 | 20 | | |
| IS (Iceland) | II2H3B/P | G 20 | 20 | G 30 + G 31 | 30 (28 - 30) |
| IT (Italy) | II1a2H, II2H3B/P, II2H3+, II2H3P | G 20 | 20 | G 30 + G 31 | Pressures 28 - 30 / 37 |
| LT (Lithuania) | | | | | |
| LU (Luxembourg) | II2E3B/P | G 20 | 20 | G 30 + G 31 | |
| LV (Latvia) | | | | | |
| MD (Moldova) | II2H3+, II2H3P | G 20 | 20 | G 30 + G 31 | Pressures 30 / 37 |
| MK (Macedonia) | II2H3+, II2H3P | G 20 | 20 | G 30 + G 31 | Pressures 30 / 37 |
| MT (Malta) | II2H3+, II2H3P | G 20 | 20 | G 30 + G 31 | Pressures 30 / 37 |
| NL (The Netherlands) | II2L3B/P, II2L3P, II2EK3B/P, II2EK3P | G 25 | 25 | G 30 + G 31 | 30 |
| NO (Norway) | II2H3B/P | G 20 | 20 | G 30 + G 31 | 30 (28 - 30) |
| PL (Poland) | II2E3B/P | G 20 | 20 | G 30 + G 31 | 30 (28 - 30) |
| PT (Portugal) | II2H3+, II2H3P | G 20 | 20 | G 30 G 31 | Pressures 28 - 30 / 37 Pressures 50 / 67 |
| RO (Romania) | II2H3B/P | G 20 | 20 | G 30 + G 31 | 30 (28 - 30) |
| SE (Sweden) | II1a2H, II2H3B/P | G 20 | 20 | G 30 + G 31 | 30 (28 - 30) |
| SI (Slovenia) | II2H3B/P | G 20 | 20 | G 30 | 30 |
| SK (Slovakia) | II2H3B/P | G 20 | 20 | G 30 | 30 |
| SRB (Serbia) | II2H3B/P | G 20 | 20 | G 30 + G 31 | 30 (28 - 30) |
| TR (Turkey) | II2H3B/P | G 20 | 25 | G 30 + G 31 | 30 + 37 |
| UA (Ukraine) | II2H3B/P | G 20 | 20 | G 30 + G 31 | 30 (28 - 30) |

12 Project planning

12.1 Continuous running fan or post-purge



Fire hazard due to failure of the combustion air fan


Failure of the combustion air fan (e.g. due to a power failure or defective motor) during operation with continuous running fan or increased post-purge may result in back radiation or hot flue gases flowing back into the burner housing. This could cause a fire.

If fail-safe continuous ventilation or post-purge is required, take appropriate measures, such as:

- ▶ installing compressed air flushing on site with:
 - sufficiently large compressed air tank,
 - normally open compressed air valve.

13 Spares


13 Spares



| Pos. | Description | Order No. |
|------|---|----------------|
| 1.01 | Cover complete | 241 050 01 022 |
| 1.02 | Screw M8 x 15 | 142 013 01 157 |
| 1.03 | Washer 7 x 18 | 430 016 |
| 1.04 | Burner housing | 241 050 01 017 |
| 1.05 | Intake housing complete | 241 050 01 012 |
| | – Screw 4 x 30 Torx-Plus | 409 325 |
| 1.06 | View port on hours counter cover | 241 210 01 197 |
| 1.07 | Connection channel with washer | 232 050 01 012 |
| 1.08 | Sealing ring NBR70 ISO 3601 | 232 050 14 047 |
| 1.09 | Fixing plate for service position | 241 050 01 247 |
| 1.10 | Grommet for connection cable | 241 050 01 177 |
| 1.11 | Housing cover | 241 050 01 037 |
| 1.12 | Treaded socket R ¹ / ₈ GES4 | 453 004 |
| 1.13 | Bracket for cable | 241 400 01 367 |
| 1.14 | Stay bolt cover | 241 050 01 357 |
| 1.15 | Flame tube WG5/1 | |
| | – Standard | 232 050 14 022 |
| | – extended by 100 mm* | 230 050 14 052 |
| | – extended by 200 mm* | 203 050 14 092 |
| | Protective cap DN 6 SELF 50/2 CF | 232 300 01 047 |
| 1.16 | Burner flange | 241 050 01 287 |
| | – Screw M8 x 25 DIN 912 | 402 500 |
| | – Washer 8.4 DIN 433 | 430 504 |
| 1.17 | Screw M6 burner housing | 241 110 01 297 |
| 1.18 | Sleeve for burner housing | 241 050 01 317 |
| 1.19 | Stay bolt for burner flange | 241 050 01 187 |
| 1.20 | Flange gasket | 241 050 01 147 |


* Only in conjunction with combustion head extension.

13 Spares




| Pos. | Description | Order No. |
|------|--|----------------|
| 2.01 | Motor ECK02/H-2 230V 50Hz 40W | 652 093 |
| 2.02 | Capacitor 3.0 µF 420V, AC, DB | 713 472 |
| 2.03 | Pressure switch LGW 3 A1 0.4 ... 3.0 mbar | 691 446 |
| 2.04 | Mounting flange for pressure switch | 605 243 |
| 2.05 | Hose 4.0 x 1.75 140 mm long | 232 050 24 047 |
| 2.06 | Hose 4.0 x 1.75 190 mm long | 232 050 24 057 |
| 2.07 | Hose clamp 7.5 | 790 218 |
| 2.08 | Fan wheel TLR-S 119 x 41.4-L S1 50Hz | 241 050 08 012 |
| 2.09 | Grub screw M6x8 w. ann. cut. edge (Tuflok) | 420 549 |
| 2.10 | Air regulator | |
| | – Standard with manual adjustment | 241 050 02 042 |
| | – with actuator 230 V | 241 050 02 052 |
| 2.11 | Intake duct | 241 050 02 032 |
| 2.12 | Manual adjustment | 241 050 02 022 |
| | Screw 4 x 30 Torx-Plus Delta PT | 409 325 |
| 2.13 | Actuator W-St02/1 220-240V 50Hz | 651 047 |
| | – Screw 4 x 30 Torx-Plus Delta PT | 409 325 |

13 Spares




| Pos. | Description | Order No. |
|------|---|----------------|
| 3.01 | Mixing head WG5N/1-A cpl. (Natural Gas) | |
| | – Standard | 232 050 14 052 |
| | – extended by 100 mm* | 230 050 14 022 |
| | – extended by 200 mm* | 230 050 14 072 |
| | Mixing head WG5F/1-A cpl. (LPG) | |
| | – Standard | 233 050 14 022 |
| | – extended by 100 mm* | 230 050 14 042 |
| | – extended by 200 mm* | 230 050 14 192 |
| 3.02 | Mixing tube WG5N/1-A cpl. (Natural Gas) | |
| | Ø internal 13 mm | |
| | – Standard | 232 050 14 012 |
| | – extended by 100 mm* | 230 050 14 012 |
| | – extended by 200 mm* | 230 050 14 082 |
| | Mixing tube WG5F/1-A cpl. (LPG) | |
| | Ø internal 8 mm | |
| | – Standard | 233 050 14 012 |
| | – extended by 100 mm* | 230 050 14 032 |
| | – extended by 200 mm* | 230 050 14 202 |
| 3.03 | Nozzle element | 232 100 14 297 |
| 3.04 | Screw M4 x 16 Torx-Plus 20IP | 409 224 |
| 3.05 | Diffuser 24 x 74 | 232 100 14 237 |
| 3.06 | Nozzle insert | 232 100 14 227 |
| 3.07 | Screw M4 x 8 Torx-Plus 20IP | 409 235 |
| 3.08 | Bracket for electrodes | 232 100 14 257 |
| 3.09 | Ignition electrode isolator 6 x 80 | 232 200 14 217 |
| 3.10 | Ignition cable | |
| | – 370 mm (Standard) | 232 050 11 042 |
| | – 470 mm (for 100 mm extension)* | 203 050 11 072 |
| | – 570 mm (for 200 mm extension)* | 230 050 11 082 |
| 3.11 | Sensor electrode | 232 100 14 207 |
| 3.12 | Ionisation cable | |
| | – 300 mm (Standard) | 232 050 14 142 |
| | – 400 mm (for 100 mm extension)* | 230 050 14 172 |
| | – 500 mm (for 200 mm extension)* | 230 050 14 182 |
| 3.13 | Carrier | 232 050 14 067 |
| 3.14 | Carrier | 232 050 14 077 |
| 3.15 | Screw M4 x 16 Torx-Plus 20IP | 409 224 |
| 3.16 | Mixing head with plate | 232 050 14 032 |
| 3.17 | O ring 15 x 2.5 NBR70 ISO 3601 | 445 014 |
| 3.18 | Cover with view port | 232 050 14 092 |
| 3.19 | View port glass | 241 400 01 377 |
| 3.20 | Grommet for ignition cable | 241 050 01 157 |
| 3.21 | Adjusting screw | 232 050 14 067 |
| 3.22 | Hexagonal nut M6 left DIN 934 -8 | 411 309 |
| 3.23 | Spring washer A5 DIN 137 | 431 613 |
| 3.24 | Hexagonal nut M5 DIN 985 | 411 203 |

13 Spares



| Pos. | Description | Order No. |
|------|--|----------------|
| 4.01 | Combustion manager W-FM05 230 V / 50/60 Hz | 600 470 |
| | – Micro fuse T6.3H, IEC 127-2/5 | 483 011 22 457 |
| 4.02 | Cover clip AGK63 | 600 312 |
| 4.03 | Plug unit ST18/7 | 716 549 |
| 4.04 | Ignition unit type W-ZG01V 230 V 100 VA | 603 229 |
| | – Closing plug | 603 224 |
| 4.05 | Screw M4 x 42 Combi-Torx-Plus 20IP | 409 260 |
| 4.06 | Plug cable No. 3 motor | 241 050 12 062 |
| 4.07 | Plug cable No. 5 W-MF | 232 200 12 102 |
| 4.08 | Plug cable No. 11 air pressure switch | 232 050 12 012 |
| 4.09 | Plug cable No.12 gas pressure switch | 232 050 12 022 |
| 4.10 | Ionisation cable No. 13 | 232 310 12 012 |
| 4.11 | Intermediate plug No. 2 | 240 200 12 012 |

13 Spares



| Pos. | Description | Order No. |
|------|--|--------------------|
| 5.01 | Valve train R $\frac{1}{2}$ with TAE complete 230 V | 232 050 26 010 |
| 5.02 | Elbow A1- $\frac{1}{2}$ -Zn-A | 453 104 |
| 5.03 | Double nipple R $\frac{1}{2}$ x 50 with Loctite | 139 000 26 717 |
| | Double nipple R $\frac{3}{4}$ x 50 with Loctite | 139 000 26 727 |
| | Double nipple R1 x 50 with Loctite | 139 000 26 737 |
| 5.04 | Flange complete Rp $\frac{1}{2}$ outlet with screws and O rings | 605 244 |
| 5.05 | O ring 3.3 x 2.4 NBR70 DIN 3601 | 445 523 |
| 5.06 | O ring 23 x 3 NBR70 DIN 3601 | 445 027 |
| 5.07 | Multifunction assembly W-MF055, 230 V | 605 240 |
| 5.08 | Solenoid coil W-MF055 D01 S20, 230 V | 605 245 |
| 5.09 | Circuit board W-MF055 D01 S20, 230 V | 605 247 |
| 5.10 | Flange complete Rp $\frac{1}{2}$ inlet with screws and O ring | 605 242 |
| 5.11 | Pressure test nipple G $\frac{1}{4}$ A | 453 005 |
| 5.12 | Pressure switch GW 50 A5/1 5 ... 50 mbar with screws and O ring | 691 378 |
| 5.13 | O ring 10.5 x 2.25 | 445 512 |
| 5.14 | Isolating valve with TAE – 998 N G $\frac{1}{2}$ CE-TAS for Gas PN1 Isolating valve without TAE – 984 D Rp $\frac{1}{2}$ PN 40/MOP5 | 454 595 454 659 |
| 5.15 | Double nipple R $\frac{1}{2}$ x 150 | 139 000 26 657 |
| 5.16 | FRS pressure regulator 505 Rp $\frac{1}{2}$, 5 ... 20 mbar | 640 675 |

14 Notes

14 Notes

14 Notes

| | | |
|-----------------------------------|--------------------|--|
| A | | |
| Air damper | 9, 36, 37, 55 | |
| Air damper setting | 36 | |
| Air number | 45 | |
| Air pressure | 46 | |
| Air pressure switch | 9, 43 | |
| Air regulator | 55 | |
| Ambient conditions | 14 | |
| Ammeter | 28 | |
| Aperture | 19, 20 | |
| Appliance category | 67 | |
| Approval data | 14 | |
| B | | |
| Bar | 66 | |
| Basic setting | 52 | |
| Basic settings | 36 | |
| Boiler room | 6 | |
| Booming | 63 | |
| Breaks in operation | 47 | |
| Burner motor | 11, 54 | |
| C | | |
| Calorific value | 32 | |
| Capacity | 16 | |
| Capacity graph | 16 | |
| Circuit board | 56 | |
| CO content | 45 | |
| Coil | 56 | |
| Combustion air | 6 | |
| Combustion chamber pressure | 16 | |
| Combustion control | 45 | |
| Combustion head | 16 | |
| Combustion head extension | 19 | |
| Combustion heat rating | 16, 36 | |
| Combustion Manager | 11, 26 | |
| Commissioning | 27 | |
| Condensate | 7 | |
| Connection pressure | 21, 22, 29, 32, 33 | |
| Consumption | 14 | |
| Conversion factor | 46 | |
| Conversion table | 66 | |
| Current measuring device | 28 | |
| D | | |
| Default settings | 36 | |
| Design lifespan | 6, 48 | |
| Diffuser | 9, 36, 37 | |
| Diffuser setting | 36 | |
| Dimensions | 17 | |
| Display | 26 | |
| Disposal | 7 | |
| Double gas valve | 10, 21 | |
| Drilling diagram | 19 | |
| Ducted air intake | 6, 16 | |
| E | | |
| Electrical connection | 25 | |
| Electrical data | 14 | |
| Electrode | 53 | |
| Electrostatic discharge | 7 | |
| Emission | 15 | |
| Emission class | 15 | |
| Error code | 59 | |
| Error codes | 60, 62 | |
| Errors | 60 | |
| ESD protection measures | 7 | |
| Excess air | 45 | |
| F | | |
| Fabrication number | 8 | |
| Fan motor | 54 | |
| Fan pressure | 28, 38 | |
| Fan wheel | 9, 54 | |
| Fault | 58, 63 | |
| Fault history | 59 | |
| Faults | 62 | |
| Filter | 10 | |
| Flame signal | 11, 28 | |
| Flame tube | 19 | |
| Flashing codes | 60, 62 | |
| Flue gas losses | 45 | |
| Flue gas measurement | 45 | |
| Flue gas temperature | 45 | |
| FRS | 10 | |
| Fuel | 14 | |
| Fuel release | 12 | |
| Fuse | 57 | |
| Fusing | 14 | |
| G | | |
| Gas connection pressure | 21, 29 | |
| Gas family | 67 | |
| Gas filter | 10 | |
| Gas isolating valve | 10, 18 | |
| Gas pressure switch | 23, 42 | |
| Gas supply | 21 | |
| Gas temperature | 46 | |
| Gas throughput | 46 | |
| Gas valve train | 18, 20, 21, 22, 32 | |
| Guarantee | 5 | |
| H | | |
| Heat exchanger | 19 | |
| High gas pressure switch | 10, 42 | |
| Hours counter | 65 | |
| Housing cover | 53 | |
| Humidity | 14 | |
| I | | |
| Ignition | 12 | |
| Ignition electrode | 53 | |
| Ignition unit | 11 | |
| Illuminated push button | 26, 58, 59 | |
| Indicating bolt | 37 | |
| Initialisation time | 13 | |
| Installation | 19, 20 | |
| Installation elevation | 14, 16 | |

15 Key word index

| | |
|-----------------------------|--------|
| Installation location | 19 |
| Installation position | 21 |
| Intake housing..... | 55 |
| Ionisation current..... | 28 |
| Ionisation electrode | 11, 53 |
| Isolating valve..... | 10, 18 |

L

| | |
|-------------------------------|------------|
| Liability..... | 5 |
| Lifespan..... | 6, 48 |
| Lockout..... | 58, 60, 62 |
| Low gas pressure switch | 10 |
| Low gas programme | 10 |

M

| | |
|------------------------------|---------------|
| Mains voltage | 14 |
| Maintenance position | 53 |
| mbar | 66 |
| Measuring device | 28 |
| Mixing head | 9, 36, 51, 52 |
| Mixing pressure | 28, 38 |
| Monitoring current | 28 |
| Motor..... | 11, 54 |
| Multifunction assembly | 10 |

N

| | |
|------------------------|----|
| Name plate | 8 |
| Noise..... | 63 |
| Nominal diameter | 32 |

O

| | |
|-------------------------------|----|
| Operating hours counter | 65 |
| Operating problems | 63 |
| Operating volume | 46 |

P

| | |
|------------------------------------|-----------|
| Pa..... | 66 |
| Pascal | 66 |
| Personal protective equipment..... | 6 |
| Plug assignment..... | 64 |
| Post-purge..... | 12 |
| Post-purge time..... | 13 |
| PPE | 6 |
| Pre-ignition time | 13 |
| Pre-purge..... | 12 |
| Pre-purge time..... | 13 |
| Pressure measuring device | 28 |
| Pressure regulator | 10, 21 |
| Pressure switch..... | 9, 42, 43 |
| Pressure switches | 39 |
| Program sequence | 12 |
| Protective equipment | 6 |
| Pulsating | 63 |

R

| | |
|-------------------|----|
| Refractory | 19 |
| Remote reset..... | 25 |
| Reset..... | 59 |

| | |
|-------------------|----|
| Reset button..... | 26 |
|-------------------|----|

S

| | |
|----------------------------|--------|
| Safety measures..... | 6 |
| Safety time..... | 12, 13 |
| Sequence diagram | 12 |
| Serial number | 8 |
| Service..... | 48 |
| Service contract | 48 |
| Service interval | 48 |
| Service plan..... | 50 |
| Service position..... | 53 |
| Setting dimensions..... | 52 |
| Setting pressure..... | 33 |
| Setting screw..... | 52 |
| Shutdown | 47 |
| Shutdown time | 47 |
| Signal lamp..... | 26 |
| Smell of gas | 6 |
| Solenoid coil | 56 |
| Sound | 15 |
| Sound power level..... | 15 |
| Sound power levels..... | 15 |
| Sound pressure level | 15 |
| Soundness test | 30 |
| Spares | 73 |
| Stability problems | 63 |
| Standard volume | 46 |
| Standards | 14 |
| Storage..... | 14 |

T

| | |
|-----------------------|--------|
| Temperature | 14 |
| Test points | 31 |
| Test pressure | 30 |
| Transport..... | 14 |
| Troubleshooting | 63 |
| Type key | 8 |
| Type of gas..... | 14, 67 |

U

| | |
|------------------------|----|
| Unit | 66 |
| Unit fuse | 57 |
| Unit of pressure | 66 |


V

| | |
|----------------------|----|
| Valve train | 22 |
| Voltage supply | 14 |

W

| | |
|----------------------|----|
| Weight..... | 18 |
| Wiring diagram | 64 |

The complete program: Reliable technology and prompt, professional service

| | | | |
|---|--|--|---|
|  | <p>W Burners up to 570 kW</p> <p>The compact burners, proven millions of times over, are economical and reliable. Available as gas, oil and dual fuel burners for domestic and commercial applications.</p> <p>The purflam® burner version with special mixing head gives almost soot-free combustion of oil with greatly reduced NOx emissions.</p> | <p>Wall-hung condensing boilers for gas up to 240 kW</p> <p>The wall-hung condensing boilers WTC-GW have been developed to meet the highest demands in ease of operation and efficiency. Modulating operation means these units operate quietly and economically.</p> |  |
|  | <p>monarch® WM Burners and Industrial Burners up to 11,700 kW</p> <p>These legendary industrial burners are durable and versatile.</p> <p>Numerous variations of oil, gas and dual fuel burners meet a wide range of applications and capacity requirements.</p> | <p>Floor-standing condensing boilers for oil and gas up to 1,200 kW</p> <p>The floor-standing condensing boilers WTC-GB (up to 300 kW) and WTC-OB (up to 45 kW) are efficient, low in pollutants and versatile in use.</p> <p>Even the largest capacities can be covered by cascading up to four gas condensing boilers.</p> |  |
|  | <p>WKmono 80 Burners up to 17,000 kW</p> <p>The WKmono 80 burners are the most powerful monoblock burners from Weishaupt. They are available as oil, gas or dual fuel burners and are designed for tough industrial application.</p> | <p>Solar systems</p> <p>The stylish flat-plate collectors are the ideal complement for any Weishaupt heating system. They are suitable for solar water heating and for combined heating support.</p> <p>With versions for on-roof, in-roof and flat roof installations, solar energy can be utilised on almost any roof.</p> |  |
|  | <p>WK Burners up to 32,000 kW</p> <p>These industrial burners of modular construction are adaptable, robust and powerful.</p> <p>Even on the toughest industrial applications these oil, gas and dual fuel burners operate reliably.</p> | <p>Water heaters/Energy storage</p> <p>The diverse program of potable water and energy storage for various heat sources includes storage volumes of 70 to 3,000 litres.</p> <p>In order to minimize storage losses, potable water cylinders from 140 to 500 litres are available with highly efficient insulation using vacuum insulation panels.</p> |  |
|  | <p>MCR Technology / Building Automation from Neuberger</p> <p>From control panels to complete building management systems - at Weishaupt you can find the entire spectrum of modern control technology. Future orientated, economical and flexible.</p> | <p>Heat pumps up to 180 kW</p> <p>The heat pump range offers solutions for the utilisation of heat from the air, the soil or ground water.</p> <p>Some systems are also suitable for cooling buildings.</p> |  |
|  | <p>Service</p> <p>Weishaupt customers can be assured that specialist knowledge and tools are available whenever they are needed. Our service engineers are fully qualified and have extensive product knowledge, be it for burners, heat pumps, condensing boilers or solar collectors.</p> | <p>Geothermal probe drilling</p> <p>With its daughter company, BauGrund Süd, Weishaupt also offers geothermal probe and well drilling. With the experience of more than 10,000 systems and more than 2 million meters of drilling, BauGrund Süd offers a comprehensive service program.</p> |  |