



Technical data sheet

ISOWINDOW FEBA SOFT ES

The one-sided window tape consists of a fleece structure that can be plastered over and is coated with a high-performance adhesive. The back is completely adhesive and has split liners. The tape is suitable for bonding to the window assembly.



ADVANTAGES

- „reversed-system“
- „fingerlift“
- soft flexible structure
- extremely strong adhesion on all types of window frame and various substrates e.g. concrete, plaster, OSB, wood, vapour barriers...
- split liners
- flexibility for movement of building component

FIELD OF APPLICATION

- for window installation inside

STANDARDS

- DIN 4108-11 including Aging
- DIN 4108-7
- ÖNORM B 8110-2
- ÖNORM B 5320
- SIA 180
- RAL-compliant

AVAILABLE DIMENSIONS

Article number	Type	Roll width	Roll length	Split liner	Carton
3FEBA75E	ES	75 mm	25 m	15 / 60	6 rolls
3FEBA100E	ES	100 mm	25 m	15 / 85	4 rolls

TECHNICAL DATA

sd-value	7 m	Material composition	Flexible fleece, laminated air-tight
Temperature resistance	-40–80 °C	Working temperature	-5–40 °C
Shelf life	12 months	Colour	White with blue ISOWINDOW print
UV-resistance	6 months	Age resistance	30 years
Storage	cool and dry		

ISOWINDOW FEBA SOFT ES

INFO

ISOWINDOW FEBA SOFT ES is attached to the window frame after installation. The fleece side of the tape can be plastered over and painted over and must face outwards. The wide adhesive surface of the tape is attached to the wall, wood, OSB or vapour barrier.

(1)

Cut the window tape with approx. 12 cm extra length. Pull the masking paper off the adhesive strip and press the adhesive tape carefully onto the window frame.

(2)

Make a fold or loop at the corners. To do so, press the window tape firmly to the window frame as far as the corner, then lift slightly, push the material along and turn 90°.

(3)

Now continue to press the window tape onto the window frame. The 'corner' fold seals the corners optimally. Do this at every corner.

(4)

When the window tape is attached to the entire window frame and the joint insulated, pull off the wide masking paper and press onto the window frame. The more pressure applied, the better the adhesion (AIRSTOP ROLL Pressing Roller, AIRSTOP RAK Plastic Squeegee)!

