



Technical data sheet

ISOWINDOW FEBA SOFT WS

The window tape two-way consists of a fleece structure that can be plastered over and is coated with a high-performance adhesive. The back is completely adhesive and has split liners. The adhesive strip covering the surface can be attached directly to the window frame without detaching a liner and the tape is completely concealed when embedded.



INSIDE
TWO-WAY

ADVANTAGES

- „fingerlift“
- soft flexible structure
- extremely strong adhesion on all types of window
- frame and various substrates e.g. concrete, plaster, OSB, wood, vapour barriers...
- alternating adhesive coating for concealed fitting
- split liners
- flexibility for movement of building component
- can be plastered and painted over

FIELD OF APPLICATION

- for window installation

STANDARDS

- DIN 4108-11 including Aging
- DIN 4108-7
- ÖNORM B 8110-2
- ÖNORM B 5320
- SIA 180
- RAL-compliant

AVAILABLE DIMENSIONS

Article number	Type	Roll width	Roll length	Split liner	Carton
3FEBA75	WS	75 mm	25 m	25 / 50	6 rolls
3FEBA100	WS	100 mm	25 m	35 / 65	4 rolls

TECHNICAL DATA

sd-value	7 m	Material composition	Flexible fleece, laminated air-tight
Temperature resistance	-40–80 °C	Working temperature	-5–40 °C
Shelf life	12 months	Colour	White
UV-resistance	6 months	Age resistance	30 years
Storage	cool and dry		

ISOWINDOW FEBA SOFT WS

INFO

ISOWINDOW FEBA SOFT WS is attached to the window frame before the window is installed. The fleece side of the tape can be plastered and painted over. The adhesive side is attached to the wall, wood, OSB or vapour barrier.

(1)

The fleece side of ISOWINDOW is covered with a narrow acrylic adhesive strip that can be attached directly to the window frame without removing a liner.

(2)

Lay the window frame with the inside facing upwards. Press the mounting strip carefully onto the window frame. Roll the ISOWINDOW along as far as the corner.

(3)

Make a fold at the corners. Do this by pressing the window tape firmly as far as the corners of the window frame, push the material along and make a fold. These 'corners' are to ensure tightness at the corners.

(4)

When the window tape is attached to the entire window frame and the joint insulated, pull off the wide masking paper and press onto the window frame. The more pressure applied, the better the adhesion (AIRSTOP ROLL Pressing Roller, AIRSTOP RAK Plastic Squeegee)!

