



Technical data sheet

ISOWINDOW UVAU ES

Window Tape one-sided provides a quick and reliable seal and vapour diffusion permeable seal for window connection joints. The tape consists of highly UV-resistant backing that can be plastered over and painted over and is fully coated with a quality acrylic adhesive. ISOWINDOW UVAU ES Window Tape is ideal for window installation that is conform with RAL and ÖNORM B 5320.



ADVANTAGES

- reversed-system
- fingerlift
- 12 months UV-resistance
- resistance to air and wind-driven rain
- soft, flexible structure
- various substrates, e.g. concrete, OSB, wood, vapour barriers
- can be plastered over and painted over

FIELD OF APPLICATION

- for window installation outside

STANDARDS

- DIN 4108-7
- ÖNORM B 8110-2
- ÖNORM B 5320
- SIA 180
- RAL-compliant

AVAILABLE DIMENSIONS

Article number	Type	Roll width	Roll length	Split liner	Carton
3UVAUSK80	ES	80 mm	25 m	20 / 60	4 rolls
3UVAUSK100	ES	100 mm	25 m	20 / 80	4 rolls

TECHNICAL DATA

sd-value	0.19 m	Material composition	PP / PU compound
Temperature resistance	-40–80 °C	Working temperature	-5–40 °C
Shelf life	12 months	Colour	Grey with black imprint
UV-resistance	12 months	Age resistance	30 years
Storage	cool and dry		

ISOWINDOW UVAU ES

INFO

ISOWINDOW UVAU ES Window Tape is attached to the window frame after installation. The grey fleece side of the tape can be plastered over and painted over and must face outwards. The wide adhesive surface of the tape is attached to the wall, wood, OSB or vapour barrier.

(1)

Cut the window tape with approx. 12 cm extra length. Pull the masking paper off the adhesive strip and press the adhesive tape carefully onto the window frame.

(2)

Make a fold or loop at the corners. To do so, press the window tape firmly to the window frame as far as the corner, then lift slightly, push the material along and turn 90°.

(3)

Now continue to press the window tape onto the window frame. The 'corner' fold seals the corners optimally. Do this at every corner.

(4)

When the window tape is attached to the entire window frame and the joint insulated, pull off the wide masking paper and press onto the window frame. The more pressure applied, the better the adhesion (AIRSTOP ROLL Pressing Roller, AIRSTOP RAK Plastic Squeegee)!

