



Technical data sheet

ISOWINDOW UVAU WS

The window tape two-way consists of a highly UV-resistant fleece backing that can be painted over and is coated with a heavy-duty adhesive. The back of the tape is completely adhesive and has separate liners. The adhesive strip covering the upper side can be attached directly onto the window frame without removing a liner, and the tape can therefore be totally concealed when installed. ISOWINDOW UVAU WS Window Tape is suitable for window installation conform to RAL and ÖNORM B 5320.



ADVANTAGES

- fingerlift
- 12 months UV-resistance
- resistance to air and wind-driven rain
- soft, flexible structure
- extremely good adhesion on all kinds of window frames and various substrates, e.g. concrete, OSB, wood, vapour barriers
- two-way adhesive coating for concealed installation
- liner split
- can be plastered over and painted over

FIELD OF APPLICATION

- for window installation

STANDARDS

- DIN 4108-7
- ÖNORM B 8110-2
- ÖNORM B 5320
- SIA 180
- RAL-compliant

AVAILABLE DIMENSIONS

Article number	Type	Roll width	Roll length	Split liner	Carton
3UVAUSK80WS	WS	80 mm	25 m	25 / 55	4 rolls

TECHNICAL DATA

sd-value	0.19 m	Material composition	Flexible fleece, laminated air-tight
Temperature resistance	-40–80 °C	Working temperature	-5–40 °C
Shelf life	12 months	Colour	Grey with black imprint
UV-resistance	12 months	Age resistance	30 years
Storage	cool and dry		

ISOWINDOW UVAU WS

INFO

ISOWINDOW UVAU WS is fixed to the window reveal before the window is installed. The fleece side of the tape can be plastered over and painted over. The fully adhesive side is attached to masonry, wood, OSB or vapour barrier. The substrate should be sufficiently supporting

(1)

The fleece side of ISOWINDOW is covered with a narrow acrylic adhesive strip that can be attached directly to the window frame without removing a liner.

(2)

Lay the window frame with the inside facing upwards. Press the mounting strip carefully onto the window frame. Roll the ISOWINDOW along as far as the corner.

(3)

Make a fold at the corners. Do this by pressing the window tape firmly as far as the corners of the window frame, push the material along and make a fold. These 'corners' are to ensure tightness at the corners.

(4)

When the window tape is attached to the entire window frame and the joint insulated, pull off the wide masking paper and press onto the window frame. The more pressure applied, the better the adhesion (AIRSTOP ROLL Pressing Roller, AIRSTOP RAK Plastic Squeegee)!

