

FormTex LED Budget

INSTRUCTIONS:

- 1) Rotate the feet 90°
- 2) Connect the power supply
- 3) Match number coded sections for lower frame
- 4) Attach horizontal support pole
- 5) Match number coded sections for upper frame
- 6) Join frame sections and connect wires
- 7) Attach front and rear graphics
- 8) Align two frames for magnetic linking

