


# 177F (1T6GQQ003) 零部件爆炸图

177F(1T6GQQ003)Part Illustrations



177F PART LIST (177F零件明细表) 1T6GQQ003

序号No.	零部件编码 Part No.	英文名称 Description	数量Quantity
1	100031627-0001	Stud, M6×61	1
2	100002321	Valve Cover	1
3	100005150	Clamp	1
4	100002859	Breather Hose	1
5	100010183	Gasket, Valve Cover	1
6	100004426	Rocker Arm Assembly	2
7	100004474	Rocker Arm Base	1
8	100004589	Valve Adjust Cap, Exhaust	1
9	100004586	Valve Spring Seat	1
10	100004584	Valve Spring Seat	1
11	100004569	Valve Spring	2

12	100004575	Valve Spring Seat	1
13	100004602	Intake Valve Seal	1
14	100002470	Bolt, M10×1.25×87	4
15	100011453-0003	Nut, M8	4
16	100006373	Muffler	1
17	100006937	Gasket, Muffler	1
18	100010392	Stud, M8×48.5	2
19	100002398	Cylinder Head	1
20	100009377	Spark Plug	1
21	100011260-0005	Bolt, M6×10	1
22	100007092	Shroud	1
23	100010362	Stud, M6-8×127	2
24	100005566	Gasket, Carburetor Insulator	1
25	100005607	Insulator	1
26	100005932	Gasket, Carburetor	1
27	100005398	Carburetor	1
28	100005954	Gasket, Air Filter	1
29	100011266-0004	Bolt, M6×20	1
30	100004711	Air Filter Assembly	1
31	100005013	Air Filter Base	1
32	100004797	Gasket, Air Filter	1
33	100004920	Muffler Sheet	1
34	100004778	Air Filter Element	1
35	100005079	Butterfly Nut	2
36	100004858	Air Filter Cover	1
37	100010817	Washer, $\phi 9 \times 1 \times \phi 16$	1
38	100011452-0003	Nut, M6	2
39	100010219	Gasket, Cylinder Head	1
40	100010562	Pin, $\phi 12 \times 20$	2
41	100004398	Push Rod	2
42	100004266	Tappet	2
43	100004529	Intake Valve	1
44	100004553	Exhaust Valve	1
45	100003247	Piston Ring Set	1
46	100003221	Circlip	2
47	100003128	Piston Pin	1
48	100003088	Piston	1
49	100003451	Connecting Rod Assembly	1
50	100010028	Oil Sensor	1
51	100011264-0003	Bolt, M6×16	2
52	100003844	Crankshaft	1
53	100010577	Woodruff Key	1
54	100004307	Camshaft	1
55	100010522-0001	Washer, $\phi 16 \times 0.5 \times \phi 24$	1

56	100010681	Bearing, 6206	2
57	100010549	Pin, $\phi 8 \times 12$	2
58	100010157	Gasket, Crankcase	1
59	100003004	Crankcase Cover	1
60	100004173-0003	Oil Plug	1
61	100004188	Dipstick	1
62	100017647	Oil Seal, $\phi 30 \times \phi 46 \times 8$	2
63	100011320-0002	Bolt, M8 $\times$ 35	7
64	100004128-0003	Dipstick	1
65	100030561	O-Ring, Dipstick	1
66	100008302	Governor Gear	1
67	100007979	Governor Gear Shaft	1
68	100010518-0001	Washer, $\phi 8 \times 0.8 \times \phi 20$	1
69	100017631	Oil Seal, $\phi 8 \times \phi 14 \times 4$	1
70	100007989	Cotter Pin	1
71	100008423	Governor Lever	1
72	100007956	Throttle Linkage	1
73	100007927	Idle Spring	1
74	100007878	Governor Spring	1
75	100011261-0004	Bolt, M6 $\times$ 12	8
76	100008150	Governor Gear Bracket Assembly	1
77	100002688	Crankcase	1
78	100010275	Earth Bolt	2
79	100010467	Washer, $\phi 12 \times 2 \times \phi 20$	2
80	100000676	Clip Base	1
81	100010040	Oil Sensor	1
82	100000655	Clip	1
83	100005137	Clamp	2
84	100017796	Fuel Hose, $\phi 4 \times \phi 8 \times 215$	1
85	100011315-0002	Bolt, M8 $\times$ 25	2
86	100008621-0005	Fuel Tank	1
87	100008767	Fuel Cap	1
88	100009315	Ignition Module	1
89	100011269-0003	Bolt, M6 $\times$ 28	2
90	100009550	Flywheel	1
91	100007032	Cooling Fan	1
92	100007559	Starter Cup	1
93	100011460-0001	Nut, M16 $\times$ 1.5	1
94	100007297-0012	Recoil Starter	1
95	100007645-0005	Blower Housing	1
96	100007386-0005	Recoil Starter	1
97	100010894-0001	Washer, $\phi 6$	3
98	100011565-0001	Bolt, M6 $\times$ 10	3
99	100009166-0001	Stop Switch	1









