

## ***JonCutter G2500 Parts Diagram List***

<b>NAME</b>		<b>BRAND</b>
Chainsaw		JonCutter Farmertec
<b>NUMBER</b>	<b>FARMERTEC#</b>	<b>PARTS NAME</b>
ZC1		Cylinder and Piston kit
ZC2	PJG250040	Oil cap
ZC3	PJG250024A	Starter Assembly
ZC4	PJG250038	Clutch
ZC5		Brake Assembly
ZC6	PJG250053	Rear Handle Assy.
ZC7	PJG250007	Crankcase Assy.
1		Hexagonal Flange Nut M5X20
2	PJG250032	Flywheel
3	PJG250033	Woodruff key
4		Small oil seal
5	PJG250036	Ball bearing 6001
6		Hexagon socket head cap screw M5X20
7	PJG250027	Cylinder pan
8		large oil seal 12X28X6
9	PJG250025	Crankshaft
10	PJG250042	Intake Manifold gasket

11	PJG250044	Piston needle bearing
12		Piston
13		Piston pin retaining ring
14		Piston pin
15		Piston Ring
16		Ignition Wire
17		Hexagon socket head cap screw M4X25
18		Spring washer
19		Flat washer
20	PJG250031	Ignition coil
21		Ignition coil Insulator
22		Spark Plug L7T
23		Single Cylinder
24		Intake Manifold
25		Hexagon socket head cap screw M4X14
26		Muffler gasket
27	PJG250034	Muffler
28		Muffler plate
29	PJG250019	handle
30		Hexagon socket head cap screw M5X45
31		Self-tapping screw ST3.9X12F

32	PJG250003	Top cover
33		Gasket
34		Ground wire
35		Hexagon socket head cap screw M5X20
36		Hexagon socket head cap screw M5X16
37		Hose connector
38	PJG250051	Fuel Hose
39		Hose Clamp
40	PJG250050	Fuel Filter
41		Tank Vent
42		Tank Vent Clamp
43		Hose
44		Hose
45		Oil cap
46		Oil cap sealing ring
47		Lug
48	PJG250043	Primer Bulb
49		Crankcase
50		Valve
51		Phillips self-tapping screw ST5X16
52		Nozzle Circlip

53		Chain stopper block
54		Hose clamp
55		Cover
56		Phillips self-tapping screw ST3.9X10F
57		Annular Mount Buffer
58		Screw ST5X14
59		Cover
60		Hook
61		Self-tapping screw ST 3.9X10F
62		Rubber stud
63		Cylindrical pin Ø5X28
64	PJG250028	Throttle handle
65		Choke Rod base
66	PJG250012	Choke Rod
67	PJG250013	Trigger control
68		Trigger spring
69	PJG250014	Trigger
70		Switch shaft
71	PJG250015	Handle bar Cover
72		Throttle Wire
73		Guide Bar Cover

74		Saw Chain
75		Guide Bar
76		Bumper Spike
77		Ring
78	PJG250035	Carburetor
79		Air Filter Base
80		Air filter cover
81		Hexagon socket head cap screw M5X45
82		Self-tapping screw ST3.9X10F
83	PJG250030	Air filter
84	PJG250004	Air filter cover
85		Screw ST3.9X12F
86	PJG250016	Lock nut
87	PJG250006	Front baffle plate
88	PJG250052	Muffler cover
89		Screw ST3.9X12F
90		Locknut M5
91		Brake Torsion Springs
92		Bushing
93		Pin Bushing
94		Screw M5X30

95		Hexagonal Nuts M8
96		Screw ST3.9X10F
97	PJG250005A	Chain Sprocket Cover Assy. ( Orange )
98	PJG250047	Brake band
99	PJG250048	Brake spring(big)
100		Brake spring support
101		Lever
102		Lever pin 3X8
103		Lever pin 3X14
104		Lever
105		Tensioner cover
106		Tensioning gear
107		Screw ST3.9X10F
108		Tensioning screw
109		Tensioning bolt
110		Brake limit spring
111		Brake limit spring cap
112	PJG250018	Brake spring cover
113		Clutch Spring
114		Clutch Block
115		Clutch Bracket

116		Clutch washer
117	PJG250037	Clutch drum
118	PJG250045	Drum Needle Cage Bearing 10X13X13
119	PJG250046	Worm
120		Worm washer Ø10XØ18X1.5
121		Oil Pump Cover
122	PJG250039	Oil Pump
123		Nozzle
124		Hexagon socket head cap screw M4X16
125		Oil hose
126		Oil filter
127		Fuel Hose Sleeve
128		Deflector
129		Self-tapping screw ST5X14
130		Flat pad Ø5.2XØ15X0.8
131		Small Rope Rotor
132	PJG250021	Start Rewind Spring Plate
133		Large Start Rewind Spring 8X0.9X645
134		Large Rope Rotor
135		Small Start Rewind Spring 0.4X0.42X1890
136		Starter cover

137		Small Handle
138		Pull rope 3X800