

Holzfforma FF120 Parts List

NAME				BRAND
Brush Cutter FF250				Holzfforma Farmertec
Nr	Pic	Farmertec	OEM	Parts Name
1-4,6,7		PJ12001	4134 020 2600	Crankcase Ass. For ST FS120/200/250
2		PJ45013PRO	9640 003 1195	FarmerBoss™ Oil Seal Set (Viton Rubber) 12x22x5 For ST FS120 FS200 FS250 FS400 FS450 FS480 FS80 FS85 FS90 FS300 FS350 FS480
4,6		T0012	9503 003 0242	Grooved Crankshaft Bearing 6201 12*32*10
5		PJ12031	4134 030 0400	Crankshaft For ST FS120 FS200 FS250
8		PJ25055PRO	9512 003 2250	FarmerBoss™ Piston Needle cage 10x13x12.5 For ST FS120 FS200 FS250
9-12		HSFS12035	4134 030 2011	piston kit with bore 35mm

9-14		QGFS12035	4134 020 1213	cylinder piston kit with bore 35mm
15		TD05280	9075 478 4175	Pan head self-tapping screw IS-D5x28 For ST FS400 FS450 FS480 Tightening Cylinder
16		T0068	0000 400 7000	Genuine NGK Spark Plug BPMR7A for chainsaws Brush Cutters and manyothers
18		PJ12030	4134 149 0600	Muffler Gasket For ST FS120 FS200 FS250
19		PJ12029	4134 140 0602	Muffler For ST FS120/200/250
20		TD05240-20A	9075 478 4159	Pan head self-tapping screw IS-D5x24
21		TD05200	0000 951 1100	Screw ST5*20

23		PJ12002	4134 084 0911	Shroud cover For ST FS120/200/250
24		PJ12039	4134 129 3000	Sealing Ring For ST FS120 FS200 FS250
25		TD05200	0000 951 1100	Screw ST5*20
26		PJ12038	4134 120 0102	Carburetor Housing For ST FS120 FS200 FS250
27		PJ12053	4128 129 0900	Carburetor Gasket For ST FS120 FS200 FS250
28		PJ12035	4134 120 0603	Carburetor W. For ST FS120 FS200 FS250
29		PJ12054	4134 123 7500	Grommet For ST FS120 FS200 FS250

30		PJ12040	4134 122 1800	Heat Shield For ST FS120 FS200 FS250
31		PJ12036	4134 129 0900	Carburetor Gasket For ST FS120 FS200 FS250
32		TD05200	0000 951 1100	Screw ST5*20
33		PJ12055	4128 182 9500	Choke knob For ST FS120 FS200 FS250
34		PJ12037	4130 350 6200	Primer Bulb Fuel Pump For ST FS120 FS200 FS250
35		BM450019		Hose 2.2x5.4x68
36		PJ12005	4134 140 2800	Filter Housing For ST FS120/200/250

37		PJ88090	9220 260 0700	Hexagon Nut M5 For ST MS880 088
38		PJ12004	4134 141 0300	Air Filter For ST FS120 FS200 FS250 FS400 FS450 FS480
166		PJ12003	4134 141 0500	Air Filter Cover For ST FS120/200/250
39-44		PJ12015PRO	4128 160 2001	FarmerBoss™ Clutch For ST FS120/200/250
42		PJ12064	0000 997 5519	Clutch Spring FS120 FS240 FS250
46		PJ12012	4134 160 2900	Clutch Drum For ST FS120/200/250
47		PJ12013	9456 621 3860	Circlip 35x1.5 For ST FS120 FS200 FS250

48		T0011APRO	9503 003 7450	FarmerBoss™ 6202-2RS Grooved Ball Bearing 15*35*11
49-55		PJ12011	4134 160 0601	Clutch Housing For ST FS120 FS200 FS250
51		PJ12011A	4137 791 9300	Rubber insert For ST FS120 FS200 FS250
56		PJ12010	4134 160 0400	Clutch Shroud For ST FS120 FS200 FS250
57		TD05280	9075 478 4175	Pan head self-tapping screw IS-D5x28
58		PJ88080	9022 341 1370	Spline screw IS-M6x30
59-66		PJ12079	4134 790 3200	Handlebar support For ST FS85 FS120 FS200 FS250

59		PJ12097	4134 791 0900	Clamp For ST FS120 FS200 FS250
60		PJ12096	4134 790 7600	Support For ST FS120 FS200 FS250
61		PJ12095	0000 997 1701	Compression spring For ST FS120 FS200 FS250 FS400 FS450 FS480
62		PJ12093	4128 791 0905	Clamp Base For ST FS120 FS200 FS250 FS400 FS450 FS480
63		PJ12094	0000 997 1304	Compression spring For ST FS120 FS200 FS250 FS400 FS450 FS480
64		PJ12068	4128 790 4800	Clamp Cover Set FS240 FS250 FS260 FS300 FS310 FS350 FS380 FS400
65-66		PJ12069	4128 790 7501	Tommy Screw FS80 FS400 FS450 FS480 FS120 FS200 FS250


67-68		PJ12067	4128 790 1701	Handle Bar FS400 FS450 FS480,FS90 FS90R FS120
69-90		PJ12041	4128 790 1301	Control Handle For ST FS120 FS200 FS250
90		PJ45020	4128 180 1104	Throttle cable For ST FS120 FS250 FS400 FS450
91		TD05240-20A	9075 478 4159	Pan head self-tapping screw IS-D5x24
93-100		PJ12018	4134 400 1301	Ignition Coil For ST FS120/200/250
99-100		PJ45071	4128 405 1000	Spark plug boot For ST FS400 FS450 FS480 FS120 FS200 FS250
100		T0090	0000 998 0604	Spark Plug Boot Torsion Spring For ST Chainsaws Brush Cutters

101		PJ12019	4134 400 1200	Flywheel For ST FS120/200/250
102	#NAME?	PJ12020	9220 260 1100	Flywheel Hexagon nut M8 For ST FS120 FS200 FS250
103		T0038	1118 195 3500	Spring
104		T0036	0000 958 0923	Washer
105		PJ12026	0000 195 7200	Starter Pawl For ST FS120 FS200 FS250
106		PJ12024	4128 195 0400	Starter Pulley Rope Rotor For ST FS120 FS200 FS250
107		T0044	0000 195 8203	Starter Rope 3.0 x 650 mm For ST 017 018 021 023 025 MS190 MS171 MS200T MS170 MS171 MS180 MS181 MS190 MS210 MS230 MS250 Chainsaw FS120 FS200 FS250 FS200

108, 110		TD03060A	9104 003 0410	Self-tapping screw P3x6
109		TP04150A	4223 084 5600	ST*15 Screw ST4*15 For ST FS450 FS120 (Tighting Spring)
111		PJ12025H	4134 190 0601	Recoil Starter Spring Assy For ST FS120 FS200 FS250 FS300 FS350 FS400 FS450 FS480
114		PJ12022	0000 190 3405	Starter Grip For ST FS120 FS200 FS250
117		TD05200	0000 951 1100	Screw ST5*20
103-117		PJ12021	4134 080 2101	Recoil Starter Assy For ST FS120/200/250
118-120		PJ12007	4128 350 0505	Fuel Cap For ST FS120/200/250

122		PJ45061	0000 989 0516	Grommet For ST FS400 FS450 FS480 FS120 FS200 FS250 FS80 FS85
123		PJ12009	4128 358 0800	Fuel Line For ST FS120 FS200 FS250
121-123		PJ12092	4128 358 0800 0000 989 0516	Grommet With Fuel Hose & 2.2x5.4x190mm Hose For ST FS120 FS200 FS250
124		T2012A	0000 350 3502	Fuel Filter Tip Diam:6.3mm Body Diam:17.5mm
118-128		PJ12006	4134 350 0400	Fuel Tank For ST FS120/200/250
127		PJ05569	1125 084 8900	Grommet For Fuel Tank FS55 FS55C FS55R FS38 FS45 FS46 FS120 FS200 FS250 FS300 FS350
128		TD05260	0000 951 1102	Screw D5x26

129, 130, 131, 138		PJ12084A	4137 710 7136 4134 711 7303 4137 711 2101	Drive Tube Flexible liner Plug Kit For FS120 FS200 FS250 FS130
132, 133		PJ05549A	4119 182 2110	Support For FS38 FS55 FS81 FS86 FS80 FS85 FS120 FS200 FS250 (Dark Grey color)
135		PJ12077	4140 007 1006	Hose clamp For FS120 FS120R FS200 FS200R FS250 FS250R FS55 FS55C FS55R
138		PJ12085	4134 711 7303	Flexible Liner 22.4x1375mm For ST FS120 FS200 FS250
139		PJ12083	4137 711 3200	Drive shaft For FS120 FS200 FS250
140-157		PJ12016	4137 640 0100 4140 640 0110	GearBox Head For ST FS120/200/250(M10*1)
142		T0081APRO	9503 003 9853	FarmerBoss™ 609-2Z Grooved ball bearing 9*24*7

144, 149		PJ12090	4130 640 7301	Set of pinions For ST FS120 FS250
150		PJ12062	4130 642 0601	Drive Shaft For ST FS120 FS200 FS250
151		HS81615APRO	9503 003 5190	FarmerBoss™ Grooved Ball Bearing 6001-2RS 12*28*8
152		BM80062	9456 621 3100	Circlip $\varnothing 28 \times 1.2$
153, 154		PJ12061	4137 710 3800 4112 717 2801	Thrust plate Guard washer For ST FS120 FS200 FS250
155		PJ12060	4130 713 1600	Thrust washer For ST FS120 FS200 FS250
156		PJ12059	4126 713 3100	Rider plate For ST FS120 FS200 FS250

157		PJ12058	4126 642 7600	Collar nut M10x1 l/h thread For ST FS120 FS200 FS250
158		TM05160	9022 341 0980	SPLINE SCREW M5X16(for tightening cover)
158, 159		PJ12091	4112 716 3100 9022 341 0980	Backing plate with 4pcs M5x16 Screw For ST FS120 FS200 FS250 FS400 FS450 FS480
158-165		PJ12045	4119 007 1027	ST TRIMMER GUARD FS80 FS85 FS90 FS100 FS120 FS200 FS250
161		PJ12066	4119 716 3200	Skirt For FS400 FS450 FS480 FS75 FS80 FS85 FS120 FS200 FS250
163-165	#NAME?	PJ12082	4119 710 6000	Blade For FS55 FS120 FS250 FS450
164		PJ12082A	4118 713 4105	Blade For FS55 FS120 FS250 FS450

165		TP05160	9074 478 4125	Pan head self-tapping screw ST5*14
-----	---	---------	---------------	--