

Holzfforma SR420 Parts List

NAME		BRAND	
Mistblower		Holzfforma Farmertec	
NO.	FARMERTEC#	OEM #	Parts Name
1	PJSR42001	4203 190 0405	Recoil Starter Assembly for ST SR340 SR420 BR320
2			NUT M8
3			WASHER8
4	PJSR42002	4223 195 0600	RATCHET
5			OIL SEAL
5-8	PJSR42003	4203 020 2106	REAR HALFCQANK CASE ASSY.
7			PIN B4X10
8			BALL BEARING
9	PJSR42004	4116 030 0400	CRANK SHAFT COMP
10			KEY
11			NEEDLE BEARING
28,12-15	QGSR42046		cylinder piston kit with bore 46mm
12-15	HSSR42046		Piston Kit 46mm
15			PISTON RING
16	PJSR42005	4203 029 0500	CRANK CASE GASKET
8, 17, 22	PJSR42006	4203 020 2106	FRANT HALFCRANK CASE
18			WASHER5
19			WASHER5
20			SCREW
21	PJSR42007	4203 400 1200	Flywheel
22			OIL SEAL
23	PJSR42010		ST SR420 Ignition Coil
24, 56-58			FUEL TANK ASSY
25			SCREW
26			TVELTANK INNERLID
27	PJSR42008	4203 029 2300	CYLINDER WASHER
29			CABLE COMP
30			CASKET
31	PJSR42009	4203 140 06014203	MVFFLER COMP
32			SCREW
33			SPARK PLOG BPMR7A
34	PJSR42011	4203 706 2102	Shroud Cover for ST SR420
35			
36			CYLINDER WASHER
37	PJSR42012	4203 122 1600	Heat Shield for ST SR420
38			LINE CLIP
39			CLEANER
40	PJSR42013	4203 120 2200	Manifold for ST SR420
41			SCREW

42	PJSR42014	4203 129 0900	Carburetor Gasket for ST SR420
43			CARBURETORCARBURETORCARBURETOR
44	PJSR42015	4203 140 2806	Filter housing for ST SR420
45			OVTLET FOEL PIPE
46			SCREW M5*20
47	PJSR42016		0 BLOCK For Holzfforma SR420
48			SCREW
49			SCREW M5*50
50	PJSR42017		0 RUBBER SEAL For Holzfforma SR420
51	PJSR42018		0 BOARD For Holzfforma SR420
52	PJSR42019		0 AIR FILTER CORE For Holzfforma SR420
53	PJSR42020	4203 140 1001	Air filter cover for ST SR420
54			SCREW M5*16
24, 55-58	PJSR42021	4203 350 0451	Fuel Tank Assy. for ST SR420
56			RUBBER LID
57			PLASTIC LID
58			

Attachments and Tools

NO.	FARMERTEC#	OEM #	Parts Name
1			BELT ASSEM
2			SUPPORT
3			NST5*20
4			WASHER 5
5			WASHER 5
6			PLASTIC CLIP
7			SCREWS T3.5*19
8			BACK MAT
9			FRAME
10			PLATE
11			SCREW M5*20
12			ANTI-VIBRATE SPRING
13			SPRING SUPPORT
14			WASHER 5
15			SCREW M5*50
16	PJSR42022	4203 700 4104	Fan housing for ST SR420
17	PJSR42023	4203 700 3401	Fanwheel for ST SR420
18	PJSR42024	4203 701 0701	Fan housing outer for ST SR420
19			NUT M5
20			LID
21			SEALING WASHER
22			PLVG
23			CLEANER
24			TANK
25			PLASTIC PIPE
26			SEALING WASHER

27			AIWALVE
28			CLIP22-38
29			RUBBER PIPE
30			CLIP22-38
31	PJSR42025	4203 708 6901	Elbow for ST SR420
32			STOPPER AXIS
33			STOPPER
34			CLIP 64-67
35			CLIP四
36	PJSR42026	4203 701 6102	Pleated hose for ST SR420
37			PIPE
38			LONG JOINT TUBE
39	PJSR42027	4203 700 6318	NOZZLE ASSY for ST SR420
40			SWALING WASHER
41			PULING
42			CONNECTOR LID
43			CLIP
44			PLASTIC PIR
45			SCREW M5*12
46	PJSR42028	0	COCK ASSEM for ST SR420
47			SUPPORT
48			SCREW M4*10
49			PLASTIC PIPE
50			CLIP
51			RZGHI CONTOROL CASE
52			SCREW M3*16
53			WASHER 3
54			AXIS SLEEPE
55			CONTACI
56			SWITCH
57			AXIS CLIP
58			SADDLEWASHER 6
59			WASHER 6
60			LEFT CONTOROL CASE
61			HANDLE一
62			HANDLE二
63			HADDLE AXIS
64	PJSR42029	4203 790 1305	Control Handle 67 mm for ST SR420
65	PJSR42030	4203 007 1013	Dusting And Granulate Spreading Kit for ST SR420
66			RVBBER PIPE
67			PIPE
68			ACROSS PIPE
69			UPRIGHT PZPE
70			CONNECTOR
71			CLIP

72			RETURN SPRING
73			REGULATOR VALVE
74			O-RING
75			NOZZLE
76			COVER BOARD (一)
77			COVER BOARD (二)
78			COVER BOARD (三)
79			CONNECTOR
80			RUBBER PLUG
81			PIN1*8