











Corner Swing Tray Installation Instruction

595.55.447 595.55.747
595.55.446 595.55.746

	A	B	C	D	E	F	G	H	I	J	K	L
	Right / Left	1Set	1Set	2Set	2Set	1Pcs	2Pcs	4Pcs	16Pcs	8Pcs	14Pcs	4Pcs
	 x2 x2											
1												
1	