


URPF20





General Guidelines


- Please read the following instruction carefully and use the product accordingly.
- Please keep this manual and hand it over when you transfer the product.
- This summary may not include every detail of all variations and considered steps. Please contact us when further information and help are needed.


Notes

- The item is only intended to be used indoors. The product must be strictly assembled and used in accordance
 with the provisions of the manual. The seller does not assume any responsibility or liability with respect to any
 damage caused by incorrect assembly or improper use.
- This item need to be assembled and please strictly adhere to the assembly steps on the instruction.
- Don't place the unwrapped item directly on the ground to avoid the paint loss and breakage. Please do not
 assemble this item on the uneven wall since the surface of the photo frame is easy to be scratched.
- Please do not let it fall down the wall during the assembly process for it may cause injuries.
- Please make sure that the photo frame is firmly fixed on the wall to avoid the falling and damage.


Warnings

- Please keep children far away from the installation area during the assembly process for it may fall down the wall and result in injuries.
- Please do not place your valuables under the photo frames.
- During the assembly process, keep small parts out of the reach of children. It may be fatal if swallowed or inhaled.
- To avoid potential danger of suffocation, keep all parts and packaging (films, plastic bags and foam, etc.) away
 from babies and children.























4

