



BISETT 120



BISETT 140






ELTAP Spółka z ograniczoną odpowiedzialnością Sp.k.
Mroczeń 203, 63-604 Baranów
www.eltap.com



mm






BISETT 120












Nr	il	dł [mm]	sz [mm]
1	1	728	559
2	1	728	559
3	1	728	598
4	1	367	541
5	1	728	367
6	1	230	781
7	4	396	157
8	4	520	114
9	4	520	114
10	4	310	100
11	4	320	524
12	1	1200	600
13	1	367	84


BISETT 140


Nr	il	dł [mm]	sz [mm]
1	1	728	559
2	1	728	559
3	1	728	598
4	1	367	541
5	1	728	367
6	1	230	981
7	4	396	157
8	4	520	114
9	4	520	114
10	4	310	100
11	4	320	524
12	1	1400	600
13	1	367	84




Assembling instruction / Montageanleitung / Notice de montage /
 Montaje de instrucción / Instrukcja montażu / Сборка инструкция /
 Montáž instrukce / Montáž inštrukcie / Szerelési utasítás /
 Сглобяване инструкция / Kurulum Talimatları / Montagem de instrução /
 Sestavljanje navodila / Montage instructie / Склапање инструкцију /
 Asamblarea de instrucțiuni / Sastavljanje upute / Montering instruktion /
 Istruzioni di montaggio / Збірка інструкція / Montāžas instrukcija /
 Montavimo instrukcija / Paigaldusjuhend / Kokoamisohjeisin










3





4






12



+





6

3

1

2



+

