


UB01 BAIT BOAT

ORIGINAL VERSION



USER MANUAL

UBDI BAIT BOAT

Product Details



UBDI BAIT BOAT



Start up

1. Place the boat on a flat road and turn on the power of the boat
 2. Push the switch of the remote control, the indicator light of the remote control is always on, the front light of the boat is not on
- Note: Do not place the boat on a slope before it is paired. Operate the left and right motors to see if they work before putting in the water

Fixed-speed cruise

1. Push the joystick up
 2. Long press the fixed-speed cruise button to enter the fixed-speed cruise mode
 3. The remote control joystick can fine-tune the direction of the boat
- Remarks: After entering the fixed-speed cruise control mode, press the fixed-speed cruise button again to exit the cruise control

Lighting control

1. Press the lighting button on the remote control, the headlights of the boat will flash. Press again to keep the headlights on, and press again to turn off the lights
2. When the boat turns left, the left tail light is always on; when the boat turns right, the right tail light is always on

Low battery reminder

1. When the boat is in a low battery state, the remote controller will make a "beep" and "beep" prompt sound
2. When the remote control is in a low battery state, the indicator light of the remote control will flash

Frequency Matching

Press the OK button on the remote control and hold, then turn on the boat switch, finally turn on the remote control switch, and when you hear a "beep" sound, the frequency pairing is complete

(When the boat is not matching with the remote control, please try this method to repair it)

UBDI BAIT BOAT



STREAMLINED HULL

2.4G REMOTE CONTROL

7.4V LARGE CAPACITY BATTERY

Battery usage and charging instructions:

● Boat battery (standard configuration)

● Connect to the power supply

This boat has a built-in battery, just connect the battery connector when using



Maintenance

- **remote control**

Please remove the battery when not in use for a long time.

- **motor**

Check the motor for debris after each use

- **Boat Hull**

1. After use, please wipe off the water to keep the hull dry and clean.
2. When the battery is not in use for a long time, please take it out and charge it for storage.
3. Do not store the boat with corrosive liquids
4. Keep away from high temperature objects.
5. When not in use, please store the boat to prevent dust.

