





No.	Parts NO.	Parts name in Engilsh
1,0		Engine Assy
1,001	201132001	Engine
1,002	G10011	Hole Spring Collar
1,003	201102002	Friction Dish 3
1,004	201102003	Friction Dish 2
1,005	201102004	Friction Dish 1
1,006	201102005	Disk Spring
1,007	201102006	Steel Wire Collar
1,008	201102007	Clutch Bottom Case
1,009	201102008	Clutch Spline
1,010	201102009	Clutch Top Cover
1,011	G01113	Bolt
1,012	G03002	Spring Washer
1,013	201102010	Connection Plate
1,014	201102011	Gasket
1,015	201102012	Gasket
1,016	201102013	Spring
1,017	G01045	Bolt
1,018	G03012	Washer
1,019	G01003	Bolt
1,020	201102014	Engine Rack
1,021	G04012	Nut
1,022	201102015	Rubber Plug
1,023	G07018	Flat Key




No.	Parts NO.	Parts name in English
2,0		Transmission Case Assy
2,001	201102016	Gear Case
2,002	G01104	Bolt
2,003	G03012	Spring Washer
2,004	G04012	Hex Nut
2,005	G02008	Flat Washer
2,006	G01084	Screw with cross head
2,007	201102017	Output Axle Cover
2,008	201102018	Seal plate
2,009	201102019	Cover
2,010	G05015	FB Seal plate
2,011	201102020	Pin
2,012	201102021	Bolt
2,013	201102022	Rubber Plate
2,014	G04005	Nut
2,015	201102023	Screw with two tip
2,016	G08032	Needle Bearing
2,017	201102024	Gear
2,018	201102025	Axle
2,019	201102026	Seal Plate
2,020	G05014	Seal plates
2,021	G08023	Ball bearing
2,022	201102027	Cover
2,023	201102028	Output Axle
2,024	201102029	Gear
2,025	G08031	Needle Bearing Assy

2,026	G08034	Needle Bearing
2,027	201102030	Gear
2,028	201102031	Double Gear Assy
2,029	201102032	Worm Rod
2,030	201102033	Axle
2,031	G08022	Ball Bearing
2,032	G08035	Needle Bearing
2,033	201102034	Gear with Spline
2,034	201102035	Gear
2,035	201102036	Connection Cover
2,036	201102037	3-position Shift
2,037	201102038	Gear
2,038	201102039	2-position Shift
2,039	201102040	Connection Shaft
2,040	201102041	Gearshift Cover
2,041	201102042	Side Cover
2,042	201102043	Side cover 1
2,043	201102044	Gasket
2,044	G08021	Ball bearing
2,045	G05011	FB Seal plate
2,046	G11003	Spring Washer
2,047	201102045	shift control 2
2,048	201102046	Connection Plate
2,049	201102047	Washer
2,050	G05003	O rubber seal
2,051	201102048	Gear Case Cover
2,052	201102049	Axle


2,053	201102049	Ruber Pin
2,054	G09011	Shaft Spring Collar
2,055	G09013	Shaft Spring Collar
2,056	G01106	Bolt with Double tips
2,057	G11008	Pin
2,058	G12004	Steel Ball
2,059	201102051	Pression Spring
2,060	201102052	seal
2,061	G11010	Pin
2,062	G01033	Screw with Countersunk head
2,063	201102053	Connection Plate
2,064	201102054	connection plate 2
2,065	G06003	Cotter Pin
2,066	G01006	Hex Head Bolt
2,067	201102055	Axle
2,068	201102056	Connection Shaft
2,069	201102057	ConnectionPlate 1
2,070	G05010	FB seal Plate
2,071	201102058	Axle
2,072	G04011	Nut
2,073	201102059	Axle
2,074	201102060	Axle
2,075	201102061	2-gearshift control
2,076	201102062	Gasket
2,077	201102063	Friction Disc 1
2,078	201102064	Friction Disc 2
2,079	G01038	Screw

2,080	201102065	Washer
2,081	201102066	Washer
2,082	G01090	Bolt
2,083	201102067	Cover
2,084	201102068	Washer
2,085	G01004	Nut
2,086	G02004	Flat Washer
2,087	201102069	Spacer Shim
2,088	201102070	Cover
2,089	201102071	Worm Wheel
2,090	201102072	Friction Plate
2,091	201102073	Flat Key
2,092	201102074	Clutch
2,093	G09016	Shaft Spring Collar
2,094	201102075	Washer
2,095	201102076	Pression Spring
2,096	201102077	Worm Shaft
2,097	G05002	O seal
2,098	201102078	Oil indicator
2,099	201102079	Oil Indicator handle
2,100	201102080	Pipe
2,101	201102081	Axle
2,102	201102082	Connection Cover
2,109	201102088	Screw
2,110	G02003	Washer
2,111	201102149	Pin


2,112	201102150	Pressure Spring
2,113	201102151	Bolt Base
2,114	G04015	Nut
2,115	201102099	Handle




No.	Parts NO.	Parts name in Engilsh
3,0	201102302	Left Wheel Assy
3,001	G01049	Hex Bolt
3,002	201102089	Metal Wheel
3,003	201102090	Tire
3,004	201102091	wheel
3,005	G02002	Flat Washer
3,006	G04001	Hex Nut
3,007	201102092	Rubber Wheel



No.	Parts NO.	Parts name in Engilsh
4,0	201102303	Right Wheel Assy
4,001	G01049	Hex Bolt
4,002	201102089	Metal Wheel
4,003	201102090	Tire
4,004	201102091	Metal Wheel
4,005	G02002	Flat Washer
4,006	G04001	Hex Nut
4,007	201102092	Rubber Wheel



No.	Parts NO.	Parts name in Engilsh
5,0		Frame Assy
5,001	G09018	Washer
5,002	201102093	Washer
5,003	201102094	Frame Base
5,004	201102095	Oil Hole
5,005	201102096	Pin
5,006	201102097	Spring
5,007	201102098	Frame
5,008	201102099	Pin Cap
5,009	201102100	Torsion Spring
5,010	G01048	Nut
5,011	G02003	Flat Washer
5,012	G04005	Locking Nut
5,013	G04015	Nut
5,014	201102101	Support
5,015	G09005	Washer
5,016	201102102	Pin
5,017	201102087	Cover
5,018	201102103	Height Control Handle



No.	Parts NO.	Parts name in English
6,0	201102301	Handle Assy
6,001	201102104	Clutch Control Wire (control implement)
6,002	201102105	Tube
6,003	201102106	Wire Connector
6,004	201102107	Left and Right Handle
6,005	201102108	Clutch Control Wire
6,006	201102109	Steel Wire Sheath
6,007	201102110	Switch Assy
6,008	201102111	Handle Sheath
6,009	G01077	Screw
6,010	G04006	Nut
6,011	201102112	Steel Wire
6,012	201102113	Wire Sheath
6,013	201102114	Steel Wire
6,014	201102115	Steel Wire Sheath
6,015	201102116	Screw
6,016	G04015	Nut
6,017	201102117	Steel Wire Sheath
6,018	201102118	Washer
6,019	G04005	Nut
6,020	G01009	Screw
6,021	G04003	Nut
6,022	G02008	Washer
6,023	G01024	Screw
6,024	G03012	Spring Washer
6,025	201101039	Locating ring

6,026	201102119	Locating ring
6,027	201102120	Torsion Spring
6,028	201102121	Clutch Control Rod
6,029	G01027	Screw
6,030	201102122	Holding Pin
6,031	201102123	Handle Assembly Base
6,032	201102124	ring
6,033	201102125	STOP Control Handle
6,034	201102126	Holding pin
6,035	201102127	Torsion Spring
6,036	G01025	Screw with hex socket
6,037	201102128	Clutch Control Rod
6,038	201102129	Screw
6,039	201102130	Plate
6,040	G06003	Cotter Pin
6,041	G02003	Flat Washer
6,042	G04002	Hex Nut
6,043	201102131	Clutch Control Rod (for worm wheel)
6,044	G01035	Countersink Hex Bolt
6,045	201102132	Cap
6,046	201102133	Compression Spring
6,047	201102134	Speed Control Handle
6,048	201102135	Handle Base
7	201102136	Gearshift Rod
8	201102137	Gearshift Rod
9	G01100	Screw with Square neck
11	G04004	Locking Nut

12	201102138	Cotter Pin
13	201102139	Connection Cover
14	201102140	Wire Cap
15	201102141	Washer
16	G03012	Spring Washer
17	G02003	Flat Washer
18	201102142	Pin
19	G09003	Shaft Spring Collar
20	G04012	Hex Bolt
21	201102143	Connector
22	201102144	Bandage
23	201102145	Washer
24	G03001	Spring Washer
25	G01050	Hex Bolt
26	201102146	Spring base
27	G01020	Screw with Socket head
28	201102147	Locking Plate
29	G04005	Nut
30	201102148	Spring