**Jabees®**

OBees
Quick Reference Guide
www.jabees.com

OBees is a V 4.1 Bluetooth Sport Headphones supporting multipoint connection and voice prompts in Chinese, English, Spanish and French .

(1) LED Light
(2) Microphone
(3) Speaker
(4) Micro USB Charging Contact
(5) Volume Up / Next Song
(6) Volume Down / Previous Song
(7) MF Button (Multifunction Button)

OVERVIEW OF OBEES:

INTRODUCTION
Thank you for purchasing our OBees Bluetooth Sport Headphone. This manual will help you to accurately operate OBees, but you should familiarize yourself with the Bluetooth function of your mobile phone or other devices before using the Bluetooth headphones OBees.

CHARGING UP OBees
1. Plug one end of the USB charging cable into OBees.
2. Plug the other end of the USB charging cable into your computer or AC charger with USB port.
3. The red indicator light will be on.
4. When the battery is fully charged, the red LED light turns off and the blue LED light turns on.

WHEN THE BATTERY IS LOW
You will hear the voice prompt "Battery Low", At this time, please charge up OBees.

Battery meter on iPhone and other iOS devices.

IMPORTANT
• For first use, please charge up OBees fully beforehand.
• You must recharge OBees if it has been not used for more than 12 months.
• You must use the authorized charger to charge up OBees.

MUTIFUNCTION BUTTON
Answer/End/Reject/Transfer Calls; Play/Pause Music;Voice Dialing; Redial; Language Selecting; Factory Reset.

TURNING OBees ON/OFF
To turn OBees on:
Long press MF button for 3 seconds. The blue LED light flashes with a voice prompt. The headphones are now turned on.
To turn OBees off:
Long press MF button for 3 seconds. The red LED light flashes with a voice prompt. The headphones are now turned off.

PAIRING OBees WITH A MOBILE PHONE
You are required to pair OBees with your mobile phone before using it.
1. Long press MF button for about 5 seconds until the blue LED light turns on with a voice prompt, and OBees is now in pairing mode.
2. Activate Bluetooth function on your mobile phone.
3. Set your phone to discover OBees and operate following the instruction.
4. If password or PIN-code is required, confirm with 0000.

PAIRING OBees WITH THE SECOND MOBILE PHONE
OBees supports multipoint technology, which means that it can be paired and connected with two Bluetooth-enabled mobile phones and use at the same time.
1. Pair and connect OBees with the first mobile phone (Please refer to PAIRING OBees WITH A MOBILE PHONE)
2. Turn off the Bluetooth function of the first mobile phone.

3. Pair OBees with the second mobile phone.
4. Turn off OBees.
5. Turn on the Bluetooth function on first mobile phone.
6. Turn on OBees again and it will automatically connect to the two mobile phones.

MAKING CALLS
Once OBees is successfully connected to your mobile phone, you can use it to make and receive calls. The headphones can be used with voice dialing if your mobile phone supports this feature. Please consult your mobile phone's manual for more information.

1. Voice Dialing
Double click MF button, and there will be voice prompt, with indicator light flashing in blue. Then say the name of the person you want to call.
2. Usual Dial
Enter and dial the number on your mobile phone as you normally do.
Once the call has been set up, the sound will be transmitted to your headphones automatically.
3. Redial
Long press MF button for 2 seconds to redial the last number you called.

ANSWERING/ENDING/REJECTING CALLS
When the headphones are turned on, and there is an incoming call, you will hear a musical tone.

-Press MF button to answer the call.
-Press MF button to end the call.
-Long press MF button for 2 seconds to reject the call.

PUT THE CALL ON HOLD
Press and hold the MF-button for 2 seconds to put the current call on hold and accept the call waiting.
Press and hold the MF-button for 2 seconds to resume to the first call.

VOICE BROADCAST FUNCTION
OBees supports voice prompts and reading incoming number.

TRANSFERRING CALLS
To transfer a call to the mobile phone, you can double press the MF-button and the blue LED light flashes with a 'beep'. If you want to transfer the call back to OBees, double press MF-button again. More procedures may be involved for some mobile phones.

ADJUSTING THE VOLUME
You can increase/decrease the volume by adjusting Volume Up/Volume Down button of OBees or your mobile phone.

Press Volume Up " + " button to increase the volume;
Press Volume Down " - " button to decrease the volume.

PLAYING/PAUSING MUSIC
Press the MF-button to play or pause music.

Long press Volume Up " + " button to play next song;
Long press Volume Down " - " button to play previous song.

LANGUAGE SELECTING
OBees supports voice prompts in Chinese, English, Spanish and French. When OBees is on and not connected with other devices, double press the "V+" button to select the language you need and you can hear voice prompt. At this time, OBees has been switched to a different language.

CONNECTING WITH A PC OR PDA
You can connect OBees with a Bluetooth-enabled PC or PDA that supports headphones or hands free profiles. Please refer to the user manual of your Bluetooth-enabled PC or PDA for setup information.

FACTORY RESET
To restore the headset to factory setting, you will have to turn off the headphones first. And then long press the MF-button for 8 seconds. When the blue LED light is off, the factory reset is successful.

GUARANTEE
Jabees is a registered trademark of FreeTek International Co, Ltd. Other brands and product names are trademarks of their respective owners. Jabees warrants this product against all defects in material and workmanship for a period of twelve (12) months from the date of original purchase of the product. The conditions of this guarantee and the extent of responsibility of Jabees under this guarantee can be read in the Warranty Card.

WARNING
Permanent hearing loss may result from long-term exposure to sound at high volumes. Use as low volume as possible and avoid prolonged use of the earphone at excessive sound pressure levels.Please read the safety guidelines below prior to using the guidelines below prior to using this earphone.

(Prior to using this product follow these steps)
1. Before putting on the earphone, turn the volume control to its lowest level.
2. Put the earphone on, and then slowly adjust the volume control to a comfortable level.

(During the use of this product)
1.Keep the volume at the lowest level as possible.
2.If increased volume is necessary, adjust the volume control slowly.
3.If you experience discomfort or ringing in your ears, immediately discontinue using the earphone. With continued use at high volume, your ears may become accustomed to the sound level, which may result in permanent damage to your hearing without any noticeable discomfort.

SAFETY INFORMATION!
1.If you have a cardiac pacemaker or other electronic medical equipment, you should consult your physician before using this product.
2.This product contains small parts that may be hazardous to children. Keep out of the reach of children. The bags themselves or the many small parts they contain may cause choking if ingested.
3.Never attempt to disassemble the product yourself, or push other objects into this product, as this may cause short circuit,which led to the fire or get an electric shock.
4.None of the components can be replaced or repaired by users. Only authorized dealer or service center may open the product.
5.If any parts of your product require replacement for any reason,including normal wear and rear or breakage, please contact your dealer.
6.If the product overheats, has been dropped or damaged or has been immersed in liquid, discontinue use.

REMEMBER:
Be sure to ensure safe driving, avoid distractions and follow local laws.

反面中文

Jabees® OBees

快速參閱指南

www.jabees.com

OBees 基於V4.1版本的藍牙運動耳機,支持多點連接功能和讀語,英語,西班牙語,法語等4種語音提示。

(1)LED指示燈
(2)麥克風
(3)喇叭
(4)USB充電孔
(5)音量減上一曲按鍵
(6)音量減上一曲按鍵
(7)多功能按鍵

圖示：

(1) (2) (3) (4) (5) (6) (7)

介紹

感謝您購買我們的OBees藍牙運動耳機,此用戶手冊將幫助您正確使用本耳機,在使用之前,您必須先瞭解和熟悉您的手機的藍牙功能或其他藍牙設備的藍牙功能的使用。

為OBees充電

1.將USB線的一端插入耳機充電孔。
2.將USB線的另一端插入帶有USB接口的充電器或者電腦USB接口。
3.充電時耳機上的紅色指示燈長亮。
4.當電池充滿時紅燈熄滅藍燈長亮。

電量低

電池電量不足時,會有語音提示
"電量不足",此時,請給OBees充電。

iPhone以及其它iOS設備上
顯示電量（如圖）

溫馨提示

* 首次使用,請先將耳機充滿電
* 如果耳機超過1個月沒有使用,請重新為其充電
* 必須選擇正規廠家生產認證過的充電器。

多功能按鍵

開關機,接聽/掛接/轉接來電,語言播放,重播,播放/暫停音樂,切換語音提示語種,喚喚出廠設置。

開機/關機

開機：
長按多功能鍵3秒,藍燈閃爍伴有語音提示,耳機開啟。
關機：
長按多功能鍵5秒,紅燈閃爍伴有語音提示,耳機關閉。

OBees與單部手機配對連接

第一次使用OBees與手機連接時必須先配對。
1.長按多功能的5秒至藍燈長亮並有語音提示,此時OBees進入配對狀態。
2.激活手機的藍牙功能。
3.手機搜索到OBees後,根據提示進行配對連接。
4.若您的手機要求密碼或PIN碼,輸入0000。

OBees與兩部手機進行配對連接

OBees支持多點連接技術,這意味著OBees能同時與兩部帶藍牙功能的手機配對連接開始。
1.開啟OBees手與第一部手機配對連接(連接方法請參考"OBees與單部手機配對連接")。
2.關閉第一部手機的藍牙功能。
3.OBees與第二部手機配對連接。
4.關閉OBees。
5.開啟第一部手機的藍牙功能。
6.重新開啟OBees,它就會自動與這兩部手機配對連接。

撥打電話

只要OBees與手機配對成功,就可以使用OBees撥打和接聽電話,如果手機支持語音播號,則可以通過OBees進行同樣的操作,更多信息,請參考手機使用手冊。

1.語音撥號
雙擊多功能鍵,將有提示音警起並在藍燈閃爍,這時說出對方的名字即可進行撥號。

2.正常撥號
在手機上進行撥號,電話接通后將自動轉移到耳機上。

3.重撥
長按多功能鍵3秒,即可重撥最近一次撥打的電話號碼。

接聽/結束/拒接電話

當耳機保持開機并與手機保持在連接狀態,來電時,將通過耳機給到鈴聲。
- 按多功能鍵聽來電。
- 按多功能鍵結束通話。
- 長按多功能鍵2秒拒接電話。

語音報號功能

當有來電時,OBees會有語音提示並讀出來電號碼。

呼叫轉移

來電也撥出電話時,從去多功能鍵,呼叫轉移到手機,并伴有藍燈閃爍和提示音;如果要將呼叫轉回耳機,再次雙擊多功能鍵,有些手機可能需要更多操作步驟。

設置呼叫等待

長按多功能鍵2秒鐘將通話轉為等待並接聽正在等待的電話。
長按多功能鍵3秒鐘轉回第一個電話。

呼叫轉移

呼叫轉移到手機和呼叫轉移回耳機
來電或撥出電話時,雙擊多功能鍵呼叫轉移回手機,如果要將呼叫轉移回耳機,再次雙擊多功能鍵,有些手機可能需要更多操作步驟。

調節音量

您可通過調節OBees或者手機來調節音量大小。
短按音量加鍵 "+" 增加音量;
短按音量減鍵 "-" 減小音量。

播放/暫停音樂
按多功能鍵播放或暫停音樂。
長按音量加鍵 "+" 播放下一曲;
長按音量減鍵 "-" 播放上一曲。

切換語音提示語種

OBees支持英語,英語,西班牙語和法語四種語言的語音提示;當耳機處於開機且未與藍牙連接狀態下,雙擊音量加鍵來切換不同語種的語音提示,您將聽到語音提示OBees已切換到不同的語言。

連接電腦或PDA 時

您可以將耳機與帶藍牙功能的電腦或支持耳機和免提模式的PDA進行連接使用,詳情請參閱您的電腦或電腦或PDA附帶以獲取相關設置信息。

恢復出廠設置

如需恢復出廠設置,需先關閉耳機,長按多功能鍵8秒后,藍燈熄滅,即設明恢復出廠設置成功。

質量保證

Jabees是飛利特國際有限公司計劃的商標,其他品牌和產品名稱是其各自所有者的商標,產品日期如購買之日起12個月內期限,如發現產品材料及工藝有缺陷,Jabees將予以保修,保修條件由Jabees所指的責任範圍可參照保修卡。

警告

長期暫露於高音量可能導致永久性聽覺受損,請儘量調低音量,避免在通電聲音響力下長時間使用耳機,在使用此耳機前,請先閱讀以下所有的安全指導原則。
（請在使用本產品前請遵照執行以下事項）
1.在最上耳機前,將音量調至最低程度。
2.戴上耳機,然後慢慢地將音量控制調整到感覺舒適的水平。

（使用本產品時）
1.僅可能維持在最低音量。
2.若需調大音量,請慢慢調整。
3.如果您慣用耳朵後或感覺耳朵嗡嗡作響,請立即停止使用耳機。如果您持續以高音量使用耳機,您的耳朵可能會暫時遇應此種音量,使用耳朵在沒有明顯久遠的情況下究竟確永久性的傷害。

安全咨詢！

1.如果您使用心臟起博器或其他電子醫療裝置,使用本產品之前請諮詢醫生的意見。
2.本產品包裝含有小小配件,可能會對小兒童造成危險,請勿將物品設定在兒童無法接觸到的地方,在使用關前請注意小零件有可能造成窒息。
3.切勿嘗試自行拆開產品,本不可將任何物品插入手機連接孔內,易在接觸濕度過高或溫度或者導致人身傷害。
4.使用者不可以自行維修本產品中的任何組件進行更換,只有授權的經銷商或維修中心才可拆開本產品。
5.如果某些任何原因造成電池過熱或冒煙,請勿使用手機,損壞或損傷,請勿使用手機。
6.如某產品過熱、產品失、產品冒火或有異味、或者掉色變調,請停止使用。

切記：

務必保證安全駕駛,避免分心,並注遵守當地法律。